

K1G Series High-Accuracy Position Sensor Global Model User's Manual

There are eight different manuals related to the K1G series. Read them as necessary for your specific requirements. (C> P. iii)



Photo of K1G-S07



Photo of K1G-C04

This user's manual describes instrumentation that uses the K1G-C04G, K1G-C04MG and K1G-C04EG, which are CE- and KC-marked controllers. Please make sure to follow the instructions for instrumentation given in chapter 2, INSTALLATION AND WIRING. The measurement cycle of 250 µs cannot be selected for these controllers.

INTRODUCTION	
WHAT TO KNOW BEFORE USE	1
INSTALLATION AND WIRING	2
INITIAL SETUP	3
ADVANCED SETTINGS	4
COMMUNICATION SETTINGS (CONNECTION TO OTHER DEVICES)	5
SZ-D01 CONFIGURATION TOOL	6
SPECIFICATIONS	7
TROUBLE SHOOTING	8
APPENDIX	9

Azbil Corporation

Please read "Terms and Conditions" from the following URL before ordering and use.

http://www.azbil.com/products/factory/order.html

NOTICE

Be sure that the user receives this manual before the product is used.

Copying or duplicating this user's manual in part or in whole is forbidden. The information and specifications in this manual are subject to change without notice.

Considerable effort has been made to ensure that this manual is free from inaccuracies and omissions. If you should find an error or omission, please contact the azbil Group.

In no event is Azbil Corporation liable to anyone for any indirect, special or consequential damages as a result of using this product.


© 2016-2018 Azbil Corporation All Rights Reserved.

 ${\sf Modbus}^{\sf TM}$ is a trademark and the property of Schneider Electric SE, its subsidiaries and affiliated companies.

EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

SAFETY PRECAUTIONS

The safety precautions explained in the following section aim to prevent injury to the operator and others, and to prevent property damage.



This device is a JIS class 1 laser product. As this device's emitter uses a semiconductor laser, observe the following cautions.

- Do not disassemble or modify sensor heads.
- Do not look into the laser beam directly.
- Do not look into the laser beam through a lens or other optical device.

Take sufficient safety measures to prevent damage or loss in the unlikely event that this device malfunctions.

Do not use this device for safety circuits designed for protection of the human body.

Do not disassemble.

Disassembly may cause electric shock or device failure.

Do not use this device in atmospheres containing corrosive or flammable gas, liquids, or powder.

Before removing, mounting, or wiring this device, be sure to turn off the power to the device and all connected devices. Failure to do so may cause electric shock.

Be sure to check that the device has been correctly wired before turning on the power. Incorrect wiring of the module can damage it or lead to hazardous conditions.

Do not touch electrically charged parts such as the power terminals. There is a risk of electric shock.

Firmly tighten the terminal screws to a torque of 0.4–0.6 N·m. If tightening is insufficient there is a risk of electric shock or fire.

\bigcirc	Do not use unused terminals on the device as relay terminals. Doing so may re- sult in electric shock, fire or device failure.
0	In the following cases, turn off the power immediately and stop using the device. • If the device gets wet (with water or another liquid). • If the device is damaged. • If the device produces an unusual smell or smoke.
\bigcirc	The power supply rating for this device is 12–24 V DC. Do not apply 100–240 V AC. Doing so may cause device failure or fire.
0	Use this device within the operating ranges given in the specifications for temperature, humidity, voltage, vibration, shock, mounting orientation, atmosphere, etc. Otherwise, fire or device failure could result.
\bigcirc	Do not block ventilation holes. Doing so may cause fire or device failure.
0	Wire this device properly, according to the directions, using the specified power source and wiring methods. Failure to do so may cause fire or device failure.
\bigcirc	Do not allow wire clippings, metal shavings, water, etc., to enter the device's case. They may cause fire or device failure.
0	If there is a risk of a power surge caused by lightning, use a surge absorber (surge protector). Failure to do so may cause fire or device failure.
0	When discarding this device, dispose of it as industrial waste, following local regulations.
0	At the time of disposal, do not allow the optical surfaces to be exposed to direct sunlight in order to prevent concentration of the sunlight, which could cause a fire.
\bigcirc	Do not try to modify or fabricate the connectors and junction cable. Doing so may cause device failure, abnormal laser beam emission, or fire.
\bigcirc	Take care that cables are not pinched or caught on something. There is a danger of disconnection.
0	Connect the controller's frame ground terminals to the ground (for K1G-C04MG, that includes the frame ground for MECHATROLINK-III, and for K1G-C04EG it includes the frame ground for EtherCAT). If the terminals are not grounded, electromagnetic interference may result.

THE ROLE OF THIS MANUAL

A total of 8 different manuals are available for the K1G series. Read them as necessary for your specific requirements.

If a manual you require is not available, contact the Azbil Group or its dealer.



K1G Series High-Accuracy Position Sensor Global Model User's Manual

Manual No. CP-SP-1397E

This manual describes the hardware and all functions of the K1G. Personnel in charge of the design, manufacture, operation, or maintenance of equipment that incorporates this device, or the design of communication software for equipment that uses this device's serial communication function, should read this manual thoroughly.



K1G High-Accuracy Position Measurement Sensor MECHATROLINK- III Communication Manual Manual No. CP-SP-1386E

This manual describes the MECHATROLINK-III communication specifications.



K1G Series High-Accuracy Position Sensor User's Manual for EtherCAT Communication

Manual No. CP-SP-1419E

This manual describes EtherCAT communications specifications.

_	
Uner's Marriel	Anne
_	Acusta

K1G Series High-Accuracy Position Sensor Controller User's Manual Manual No. CP-UM-5783JE

Personnel in charge of the design or configuration of equipment that incorporates this device should read this manual thoroughly. The manual covers safety precautions, installation, wiring, and primary specifications.



K1G Series High-Accuracy Position Sensor Head User's Manual Manual No. UM-5784JE

Personnel in charge of the design or manufacture of equipment that incorporates the sensor heads should read this manual thoroughly. It covers safety precautions, installation, wiring, and primary specifications.

University Annual	

Handling Precautions for the SZ-D01 Configuration Tool for K1G Series High-Accuracy Position Sensors Manual No. UM-5785JE

Personnel who use the configuration tool for K1G sensors should read this manual. The manual covers safety precautions, installation, and wiring.

_	
UsereManan	Anumer Anumer
-	Acume

Handling Precautions for K1G Series High-Accuracy Position Sensor Junction Cables Manual No. UM-5787JE

Personnel in charge of the design or manufacture of equipment that incorporates these cables should read this document thoroughly. It contains safety precautions.

чисталиски Мисталиски Диника	
Auros	

Attachment Instructions for Ferrite Core and Shielded Junction Cables for K1G Series High-Accuracy Position Sensors Manual No. CP-UM-5810JE

Please read this manual if you use a CE- or KC-marked global model of the K1G series. This manual covers safety precautions, installation, and wiring.

Thank you for purchasing this Azbil Corporation product. This manual contains information for ensuring the safe and correct use of the product.

It should be read by those who design or maintain a control panel or other equipment that uses this product.

Also, the manual provides necessary information for installation, maintenance, and troubleshooting. Be sure to keep the manual nearby for handy reference.

CONVENTIONS USED IN THIS MANUAL

	: Indicates a tip for configuration or operation.
! Handling Precautions	: Pay attention to the indicated points when handling the product.
	: Refer to the indicated item or page.
123	: Numbers indicate steps in a procedure.
8888	: This font indicates what is shown on the 7-segment display.
	: Keys on the operating panel

NOTES ON LASERS

This set of sensor heads is a class 1 laser product using a semiconductor laser as the light source.

For this reason, note the following.

- Do not disassemble or modify sensor heads.
- Do not look into the laser beam directly.
- Do not look into the laser beam through a lens or other optical device.

Sen	sor head model No.	K1G-S07	K1G-S15
Em	nission wavelength	650	nm
	Output	Less than	0.39 mW
	Pulse width	25 µs	100 µs
Laser class	JIS standards	Class 1 laser p	product (JIS C)
IEC 60825-1		Class 1 Las	er Product
	FDA (CDRH) Part 1040.10	Class 1 Lase	er Product *

* The class is based on the IEC 60825-1 standard, following Laser Notice No. 50 of the Center for Devices and Radiological Health (CDRH) of the Food and Drug Administration (FDA).

HANDLING PRECAUTIONS

- As part of setup work or operation, check that this device is operating properly.
- If this device is used in combination with other devices, its functions and performance may not meet specifications, depending on the operating conditions and environment. Consider the combination carefully before use.

INSTALLATION ENVIRONMENT

To ensure the safe and correct use of the product, do not install it where it will be exposed to any of the following:


- Outdoor weather
- Direct vibration or shock
- Corrosive or combustible gas
- Steam, dust, or oily smoke
- Water, oil, organic solvents such as thinner, or other chemical substances used in processing (direct exposure)
- Sources of electrical noise
- Strong magnetic fields
- Sunlight or other strong light

EFFECTS OF DIRT OR AMBIENT LIGHT INTERFERENCE

Proper measurement may not be possible due to dirt or interference from ambient light.

- Do not allow dust, dirt, water, oil, or fingerprints to remain on the light-emitting or receiving surfaces of the sensor heads. After turning off the laser, clean the affected surface with a soft dust-free cloth.
- Use some kind of shielding to prevent external light with a wavelength of around 650 nm from striking the light-receiving surface of the sensor head.

PRECAUTIONS FOR WIRING



- Before wiring, be sure to check the model number and terminal numbers, referring to the label on the side of the device. After wiring, be sure to check that there are no mistakes.
- For screw terminal connections, use crimp terminals that are the correct size for M3 screws. The tightening torque for terminal screws is 0.4 to 0.6 N·m.
- The I/O signal wires should be at least 50 cm away from power wiring for motors, etc., and from power lines. Also, do not put these two types of wires in the same conduit or wiring duct.
- Be careful not to allow crimp terminal lugs, etc., to touch adjacent terminals.
- Make sure that connected devices or equipment have a basic level of insulation suitable for the maximum voltages of this device's power source and input/output components.

CABLES FOR THE K1G

Use JCS4364-compliant instrument cable or equivalents for K1G-C04G inputs and outputs (twisted shielded instrument cable).

The following cables are recommended.

Fujikura Ltd.	2 cores IPEV-S-0.9 mm ² ×1P	
	3 cores	ITEV-S-0.9 mm ² ×1T
Hitachi Metals, Ltd.	Ltd. 2 cores KPEV-S-0.9 mm ² ×1	
	3 cores	KTEV-S-0.9 mm ² ×1T

If there is relatively little electromagnetic induction, shielded multi-core microphone cables (MVVS) can be used.

Use power cables with a nominal cross-sectional area of 0.75–2.00 mm², a rated voltage of 300 V or more, and a rated temperature of 60 $^\circ$ C or more.

If off-the-shelf cable is used, the equivalent of CVV or VCT cable is recommended.

Use cables whose cross-sectional area is suitable for the crimp terminal lugs used. Cable length must be no longer than 30 m.

COMMUNICATION CABLES FOR MECHATROLINK-III

Use industrial mini I/O connectors for the communication cable of the MECHATROLINK-III that connects to the K1G-C04MG. RJ-45 connectors are not compatible.


COMMUNICATION CABLES FOR ETHERCAT

For the EtherCAT communication cable connected to the K1G-C04EG, use a Cat 5e or higher STP cable. The use of a double-shielded STP cable is recommended in an environment with heavy electrical noise (for example, an FA equipment environment).

TERMINAL CONNECTION

Firmly tighten the terminal screws to a torque of 0.4–0.6 N·m. If tightening is insufficient there is a risk of electric shock or fire.

Do not use unused terminals on the device as relay terminals. Doing so may result in electrical shock, fire or device failure For controller connections, use crimp terminals compatible with M3 screws.



Compatible screw	Termi	nal dim (mm) B	ensions	Recommended crimp terminal (JIS standards)	Compatible wire size
M3	6.1	5.8	5.8	RAV1.25-3	0.3–1.3 mm ² 22–16 AWG

! Handling Precautions


- In a place subject to vibration or shock, be sure to use round crimp terminals to prevent disconnection.
- Be careful not to allow crimp terminal lugs to touch adjacent terminals.
- The tightening torque for terminal screws is 0.4 to 0.6 N·m.


WIRING OF THE POWER AND GROUND

Before mounting, removing, or wiring, be sure to turn off the power to this device and all connected devices.

Failure to do so may result in electric shock.

The power supply rating for this device is 12–24 V DC. Do not apply 100–240 V AC. Doing so may cause device failure or fire.



Use the frame ground terminals of this device (A3 and the network frame ground terminals*) for one ground connection only. Do not run wiring across to other terminals. If it is difficult to wire the shielded cable, etc., use a separate ground terminal (earth bar). 

*K1G-C04MG: terminal C7. K1G-C04EG: terminal C1 The K1G-C04G has no network frame ground terminal.

WARM-UP

After the power has been turned on, wait for at least 30 minutes before use. Because the device's circuitry does not stabilize immediately after the power has been turned on, the measured value may change gradually.

POWER-ON RESET

The device begins making measurements about one second after the power has been turned on.

After the output response time has passed, analog output (AO) or digital output (DO) begins.

A request to establish a MECHATROLINK-III communications connection can be accepted about one second after the power has been turned on.

For EtherCAT communication, check the specifications of the master device that the K1G is used with, and verify the startup operation of the actual device before use.

Contents

Introduction

Chapter 1.	WHAT TO KNOW BEFORE USE 1-1
1-1	About the K1G Series 1-2
1-2	Check of Included Items 1-4
1-3	
1-4	Names and Functions of Parts1-9
Chapter 2.	INSTALLATION AND WIRING 2-1
2-1	Installing the Sensor Heads
	Install the controller in the panel. 2-3
2-3	Connecting the Sensor Heads 2-5
	Wiring the Controller (all models) 2-7
2-5	Wiring the Controller (K1G-C04G)
2-6	Wiring the Controller (K1G-C04MG)2-14
2-7	Wiring the Controller (K1G-C04EG)2-15
Chapter 3.	INITIAL SETUP
Initia	al Setup Flowchart
3-1	Analog Output (AO) Settings
3-2	Digital Input/Output (DI/DO) Settings
3-3	Setting the Station Address for MECHATROLINK-III
3-4	Setting the Number of Transmission Bytes for MECHATROLINK-III3-6
3-5	Setting the Measurement Cycle
3-6	Receiver adjustment 3-8
3-7	Setting the ECAT ID (for K1G-C04EG only)3-11
Chapter 4.	ADVANCED SETTINGS 4-1
4-1	Settings that Can Be Changed 4-2
4-2	Changing the Display 4-5
4-3	Changing the Measurement Settings4-11
4-4	Changing the Analog Output (AO) Settings4-25
4-5	Using Digital Input (DI) and Digital Output (DO)4-36
4-6	Calculations that Use Measured Data4-61
4-7	Using Special Functions 4-76

4-8	Other Functions
4-9	Changing MECHATROLINK-III Communication Settings 4-108
4-10	Returning All Settings to the Defaults
Chapter 5.	COMMUNICATION SETTINGS
•	(CONNECTION TO OTHER DEVICES)
5-1	Overview of Communications
51	Changing the Communications Conditions 5-4
5-3	Message Format
	Function Codes 5-16
51	
Chapter 6.	SZ-D01 CONFIGURATION TOOL
6-1	System Configuration
	Installation and Wiring 6-4
6-3	Basic Operation and Functions 6-7
Chapter 7.	SPECIFICATIONS7-1
7-1	Sensor Heads 7-2
7-2	Controllers 7-5
7-3	Junction Cables 7-8
7-4	Ferrite core
Chapter 8.	TROUBLE SHOOTING
Trou	ibleshooting
Chapter 9.	APPENDIX
9-1	Parameters 9-2
9-2	Configuration Flowcharts 9-7
9-3	Processing Flowchart 9-12
9-4	Alphanumeric Characters 9-13
9-5	If the Product Is Used Outside Japan9-14
9-6	Communication Parameters 9-15
9-7	Important Notes for Restarting the Laser Beam9-31

WHAT TO KNOW BEFORE USE


This chapter gives an overview of K1G series sensors and the names and functions of their parts.

1-1	About the K1G Series1-2
1-2	Check of Included Items1-4
1-3	Optional Parts1-7
1-4	Names and Functions of Parts1-9

1-1 About the K1G Series

SYSTEM CONFIGURATION

The K1G series features a semiconductor laser emitter and a receiver with a line image sensor. These two sensor heads measure the position of a workpiece that is between them.




*1 Necessary for connecting the sensor head cable to the sensor heads

*2. The K1G-C04MG supports MECHATROLINK-III communication and the K1G-C04EG supports EtherCAT communication.


Max. cable length: 25 m

EXAMPLES OF K1G MEASUREMENTS


Determining edge position




Sensing the edge's status




Measuring blocked light width




Sensing the edge's status




Measuring width of light through gap






1-2 Check of Included Items


SENSOR HEADS



Note: This product has been registered with the FDA (CDRH). It includes a label indicating compliance with FDA standards. In the case of export to the United States, attach the label to the product.

CONTROLLER






SHIELDED JUNCTION CABLE

The standard model or bend-tolerant model can be selected according to the installation conditions.

Necessary for connection of the sensor head cable to the sensor heads.

Shielded cables are also available.




! Handling Precautions

• If the cable is installed on a movable part, a bend-tolerant cable should be used.

FERRITE CORE


Be sure to attach the ferrite core to the sensor head cable and the power cable of the controller.



1-3 Optional Parts

FRONT PANEL PROTECTIVE COVER FOR CONTROLLERS

This cover protects the controller front panel and prevents operator errors. It can be opened and closed. ________Model No. 81441421-001 ______



NOISE FILTER

If there is a considerable amount of electrical noise from the power supply, a noise filter is used in combination with an isolation transformer. Choose the proper type according the noise.

— Model No. 81442557-001


Line filter

— Model No. 81446365-001

CR filter: for quick-rising noise

K1G CONFIGURATION TOOL

This tool especially made for the K1G series is used for setup, parameter configuration, and monitoring.




1

SENSOR HEADS

! Handling Precautions

• Be sure that the emitter and receiver have the same serial number. If an emitter and receiver with different numbers are used, the product may not meet the listed specifications.




	Name	Description		
1	Light-emitting surface	Laser beam emitting surface		
2	Light-receiving surface	Laser beam receiving surface		
3	Orientation indicator	T: Top, B: Bottom		
4	Serial No.	Be sure that the emitter and receiver have the same serial number		
5	Light emission indicator	Lit when the laser beam is emitted*		
6	Emitter cable	Black		
7	Light reception indicator	Used for adjusting the beam alignment		
8	Receiver cable	Black		
9	Model No.			
10	Mounting holes	Thru-holes for M3 screws		

* When the power is first turned on, the indicator may light up temporarily, but the laser beam is not emitted at this time.

Front


CONTROLLER



Name		Description		
1	Operation and channel indicators	Run Ch1 Ch2 Ch3 Ch4 Lit to indicate which channel's mea- sured value is displayed on display 1. Lit while the status is "Run." Lit while the controller is operating properly.		
2	Display 1	Displays the measured value.		
3	Auxiliary display	Displays a setting that is being checked or changed.		

Name		Description				
4	Display 2	Displays the measured value.				
5	Status indicators	 Indicate the operating status of the channel selected for display 1. Hold — Lit when the status of the measured value is "Hold." Max — Lit when the max. digital input (DI) constant output function is used. Min — Lit when the min. digital input (DI) constant output function is used. 				
6	Sensor connection indicators	Indicate channel(s) to which sensor heads are connected. 1 2 3 4				
7	Digital input/out- put indicator	Indicates digital I/O status by lighting up when digital I/O is on.				
8	Key functions	Image: Second System Weight System Weight System Weight System Image: Second System Weight System Weight System Weight System Image: Second System Weight System Weight System Weight System Image: Second System Weight System Weight System Weight System Image: Second System Weight System Weight System Weight System Image: Second System Weight System Weight System Weight System Image: Second System Weight System Weight System Weight System Image: Second System Weight System Weight System Weight System Image: Second System Weight System Weight System Weight System Image: Second System Weight System Weight System Weight System Image: Second System Weight System Weight System Weight System Image: Second System Weight System Weight System Weight System Image: Second System Weight System Weight System Weight System Image: Second System Weight System Weight System Weight System Image: Second System				





	Name	Description		
9	Sensor head cable connector	Connects the included sensor head cable and controller.		
10	Terminals	Used for wiring of the power and input/output signal wires.		
	LEDs for MECHATROLINK-III	ERR L LK1 CON L LK2 LK1 (link 1, green): Lit when link CN1 is estab- lished LK1 (link 2, green): Lit when link CN2 is estab- lished ERR (error, red): Lit when an error occurs with MECHATROLINK-III CON (connection, green): Lit when a connec- tion is established		
12	Connector 1 for MECHATROLINK-III	-		
13	Connector 2 for MECHATROLINK-III	-		
[14]	ECAT ID setting switch	Sets the ECAT ID in two hexadecimal digits X10: 2nd digit X1: 1st digit		

	Name	Description		
[5]	RJ45 port	Connects the network cable for EtherCAT com- munication. ECAT OUT: EtherCAT communica- tion OUT port ECAT IN: EtherCAT communica- tion IN port Link/Activity indicator: Green Shows the state of the EtherCAT communica- tion port physical link and data transmission.		
[6]	EtherCAT RUN/ERROR LED	 RUN ERROR RUN indicator: Green Indicates the state of EtherCAT communication. ERROR indicator: Red Indicates an EtherCAT error. 		

DETAILS ON ETHERCAT INDICATORS

Types of indicator states

Indicator states Definition			
Off	Constantly OFF		
Flickering	ON for 50 ms and OFF for 50 ms		
Blinking	ON for 200 ms and OFF for 200 ms		
Single Flashes	ON for 200 ms and OFF for 1000 ms		
Double Flashes	ON for 200 ms and OFF for 200 ms and ON for 200 ms and OFF for 1000 ms		
On	Constantly ON		

Link/Activity LED: Green

Indicator states	Description	
Off	No link	
On	Link but no communication activity	
Flickering	Link with communication activity	

RUN LED: Green

Indicator states Description		Description		
Off	INIT	No communication is available.		
Blinking	PRE-OPERATIONAL	Only mailbox communication is available.		
Single Flashes	SAFE-OPERATIONAL	Process (input) data communication and mailbox communication are available.		
On	OPERATIONAL	Process (input and output) data communica- tion and mailbox communication are available.		

ERROR LED: Red

Indicator states Description		Description		
		There is no EtherCAT error, or the device is not communicating.		
Blinking	EtherCAT communi- cation setting error	Invalid configuration for EtherCAT communi- cation. Change the settings.		
Single Flashes	Device behavior error	There is a controller application error.		
Double Flashes	Process data watch- dog timeout or EtherCAT watchdog timeout	Sync Manager Watchdog timeout or Ether- CAT communication timeout has occurred. Check the communication cable connec- tions.		
On	PDI watchdog time- out	PDI Watchdog timeout has occurred. There is a problem with the device. If the con- troller does not return to normal after the power is turned off and back on, replace the device.		



INSTALLATION AND WIRING

This chapter describes installation and wiring of the sensor heads and controller.

2-1	Installing the Sensor Heads2-2
2-2	Install the controller in the panel2-3
2-3	Connecting the Sensor Heads2-5
2-4	Wiring the Controller (all models)2-7
2-5	Wiring the Controller (K1G-C04G)2-8
2-6	Wiring the Controller (K1G-C04MG)2-14
2-7	Wiring the Controller (K1G-C04EG)

2-1 Installing the Sensor Heads


SAFETY PRECAUTIONS

Do not do work while power is supplied. There is a risk of electric shock or device failure.

Do not use this device in atmospheres containing corrosive or flammable gas, liquids, or powder.

Install the emitter and receiver so that the lightemitting and receiving surfaces face each other

Secure the sensor heads to a jig, etc. using commercially available M3 screws, working from the sensor side.



Tightening torque: 0.5 N·m max.

! Handling Precautions


- Secure the cable in a way that avoids stress where it exits the device and near the connector.
- Do not touch the optical surfaces during installation.
- Be sure that the emitter and receiver have the same serial number.
 If an emitter and receiver with different numbers are used, the product may not meet the listed specifications.
- Attach the sensor heads securely so that they will not come loose by vibration or shock.
- · Install so that the workpiece does not come into contact with the sensor heads.
- · Do not remove the sensor heads while power is being supplied.
- Pay attention to the orientation of the emitter and receiver during installation.


2-2 Install the controller in the panel.


1 Make a cutout in the panel

The controller is a panel-mount type. Make a cutout in the panel according to the following dimensions.

Individual mounting







Note: N represents the number of controllers.

! Handling Precautions

- If three or more units are gang-mounted, the ambient temperature should not exceed 35 $^{\circ}\mathrm{C}.$
- During installation, leave clearance of at least 50 mm above and below.


2 Insert the controller into the cutout

Insert the controller from the front side of the panel.

Unit: mm

3 Attach the mounting brackets

Attach the included mounting brackets to the top and bottom of the controller. Attach the bottom bracket first.



Tighten the screws

Tighten the screws of the mounting brackets until there is no more play between the bracket and screw and panel, and then turn one revolution more only.

! Handling Precautions

- Excessive tightening of the screws can deform the controller case.
- The mounted controller should not be inclined from the horizontal by more than 10 degrees upward or downward.
- The mounting panel should be made of a rigid material 7 mm thick or less.

4


Attach the cables

! Precautions for wiring



• Secure the cable in a way that avoids stress where it exits the device and near the connector.

• Sensor head cable



Cable length: Connector type: Bend radius: Identification: 0.4 m socket (panel-mount) R30 Each branched cable has a channel No. The cables for the receiver have an identifying mark.

• Junction cable



Junction cable

Cable length:

Connector type: Bend radius:

Identification:

1–25 m (standard model) 1–3 m (bend-tolerant model) Socket R35 (K1G-L _ _ S) R40 (K1G-R _ _ S) Bend-tolerant cables for the receiver have an identifying mark.

Handling Precautions

• The junction cable cannot be connected to another junction cable.

Sensor heads



Sensor heads

Cable length: Connector type: Bend radius: Identification: 0.2 m Socket (panel-mount) R30 The receiver has an identification mark.

! Handling Precautions


 After operation has begun, in order to switch to a different sensor head model it is necessary to reset the sensor head settings.

伊 P. 4-106

2 Attaching ferrite cores

Attach the SZ-E01 ferrite cores to the cables of the sensor heads (emitter and receiver), making 2 turns (1 loop).

Run the cable and attach it in a way that avoids tension where the cable enters the sensor head.




Connecting shielded junction cables

Connect the junction cable to the connectors at the controller end and the sensor head end, and cover the cable including both connectors with an electromagnetically shielded conduit or the like.

Ground the shielded ground wire of the junction cable. (A spade terminal compatible with M3 screws is attached to the end of the shielded ground wire.)

In the case of K1G-L $_$ S, the junction cables for the emitter and receiver can be put in the same electromagnetically shielded conduit (etc.). In this case, ground all shielded ground wires.




3

ATTACHING THE FERRITE CORE

Attach the SZ-E02 ferrite core to the power wires (not included with the product) to the controller, making 2 turns (2 passes through the core) for the K1G-C04G and K1G-C04MG and 3 turns for the K1G-C04EG. Both power wires (V+ and V-) must be passed through the core.


Connect the controller's frame ground terminal (A3) to the frame ground of the equipment.

After attaching the ferrite core, run the power wires and connect them.



2-5 Wiring the Controller (K1G-C04G)

TERMINAL LAYOUT




	A		С		F	
1	Power +	Pow	DA	Com	AO1 +	
2	Power -	Power supply	DB	Communication	AO1 -	An
3	FG	pply	SG		AO2 +	
4	DO1		DI1		AO2 -	alog
5	DO2	Out	DI2	Input	AO3 +	Analog output
6	DO3		DI3		AO3 -	
7	DO4		DI4		AO4 +	
8	DO5	Output	(Emp	ty)	AO4 -	
9	D06					
10	D07		Concorb			octor
11	DO8		Sensor head cable connecto			
12	(Emp ⁻	ty)				

! Handling Precautions

- Be sure to check that the module has been correctly wired before turning on the power. Mistakes in wiring can damage the device.
- Connect the controller's frame ground terminal (A3) to the frame ground of the equipment.


WIRING OF DIGITAL OUTPUT (DO)




Output current (source or sink): 1 to 10 mA (per output)ON-state voltage drop:2 V max.OFF-state leakage current:0.3 mA max.Common type:8 (shared with power terminals)


• 0 V

WIRING OF DIGITAL INPUT (DI)





Input circuit




! Handling Precautions

• Do not connect digital outputs (DOs) and digital inputs (DIs) directly. To make a connection between them, install pull-up resistors for NPN or pull-down resistors for PNP in the external circuit. Select pull-up resistors or pull-down resistors so that the load current is about 10 mA.


Input current	NPN: Approx. 3 mA
	PNP: Approx. 1 mA (at 12 V DC)
	Approx. 4 mA (at 24 V DC)
Min. input time	: 12 ms (at a 500 μs measurement cycle)
	24 ms (at a 1 ms measurement cycle)
Common type	4 (shared with power terminals)

WIRING OF ANALOG OUTPUT (AO)



Note: AO1-, AO2-, AO3-, and AO4- are all connected inside this device.

Analog output circuit




! Handling Precautions

• If the analog outputs of the K1G and another device are connected to the same analog input device, the K1G's output signal may become unreliable due to factors such as the current coming from other circuits. In this case, attach an isolator between the K1G and the analog input device.


Load resistance: 10 k Ω min. (with voltage output) $250 \ \Omega + 1 \ \% \ max. \ (with \ current \ output)$

RS-485 COMMUNICATIONS

If devices with 3-wire and 5-wire systems are both used




• When only devices with a 3-wire system are used



2-6 Wiring the Controller (K1G-C04MG)

TERMINAL LAYOUT




Power supply		MECH	ATROLINK-III
A1	Power +	CN1	Connector 1
A2	Power -	CN2	Connector 2
A3	FG	C7	FG

! Handling Precautions

- Be sure to check that the module has been correctly wired before turning on the power. Mistakes in wiring can damage the device.
- Connect the controller's frame ground terminals (A3 and C7) to the frame ground of the equipment.

2-7 Wiring the Controller (K1G-C04EG)

TERMINAL LAYOUT



Power supply		E	therCAT
A1	Power +	CN1	ECAT OUT
A2	Power -	CN2	ECAT IN
A3	FG	C1	FG

! Handling Precautions


- Be sure to check that the module has been correctly wired before turning on the power. Mistakes in wiring can damage the device.
- There are two types of EtherCAT communication port: host (ECAT IN) and slave (ECAT OUT) If the cable is connected to the wrong port, the device cannot communicate.
- Connect the controller's frame ground terminals (A3 and C1) to the frame ground of the equipment.

WIRING METHOD

To use the K1G-C04EG properly, be sure to follow the wiring method described below.


Sensor head cable

• Attach the ferrite cores to the sensor head cables.



Communication cable

- · Use a double-shielded cable (not included) for communication.
- Remove the jacket at both ends and ground the shield using a cable clamp (not included).





For more general information on how to install EtherCAT products, please refer to ETG.1600, EtherCAT Installation Guideline, issued by EtherCAT Technology Group.

If the controller is used in an environment with a large amount of electromagnetic noise, take the necessary countermeasures in the following ways.

- Move the controller and cables away from the noise source.
- Make more turns (2) when attaching the ferrite cores to the sensor head cables.




INITIAL SETUP

The chapter describes the initial setup after the power to the controller has been turned on for the first time.

Initi	al Setup Flowchart
3-1	Analog Output (AO) Settings
3-2	Digital Input/Output (DI/DO) Settings3-4
3-3	Setting the Station Address for MECHATROLINK-III3-5
3-4	Setting the Number of Transmission Bytes for MECHATROLINK-III . 3-6
3-5	Setting the Measurement Cycle
3-6	Receiver adjustment3-8
3-7	Setting the ECAT ID (for K1G-C04EG only)

Initial Setup Flowchart



3-1 Analog Output (AO) Settings



-

Analog output settings applies to all channels. The parameters cannot be changed for individual channels.

Select the output method

UollageVoltage output (1–5 V)CrockCurrent output (4–20 mA)

Display







Save the parameter



Press \bigcup_{Enter} to save it.



To change the analog output method, return all settings to the default values.

4-10 Returning All Settings to the Defaults (P. 4-114)



3-2 Digital Input/Output (DI/DO) Settings





The digital input/output applies to all channels. The parameters cannot be changed for individual channels.

1 Select the input/output method



Select <i>nPn</i> or <i>PnP</i> using	ng
---------------------------------------	----

Parameter	Description
nPn	NPN input/output
PnP	PNP input/output



Display



2 Save the parameter



Press \bigcup_{Enter} to save it.



To change the digital input/output settings, return all settings to the default values.

4-10 Returning All Settings to the Defaults (P. 4-114)

3-3 Setting the Station Address for MECHATROLINK-III



1 Select the station address.



Select the station address using $\otimes / \otimes \otimes / \otimes$.

Parameter	Description
3h to EFh	Station address







Save the address



Press \bigcap_{Enter} to finalize your selection.



The station address for MECHATROLINK-III can be changed after the initial setup is completed.

C 4-9 Changing MECHATROLINK-III Communication Settings (P. 4-108)

3-4 Setting the Number of Transmission Bytes for MECHATROLINK-III



1 Select the number of transmission bytes



Choose 48 or 32 using (%)/(%	. 48 or 32 using ⊗/⊗).
------------------------------	----------------------	----

Parameter	Description
48	No. of transmission bytes 48
32	No. of transmission bytes 32



Display



2

Save the number of transmission bytes



Press \bigcap_{Enter} to finalize your selection.



The number of transmission bytes for MECHATROLINK-III can be changed after the initial setup is completed. SETTING THE NUMBER OF TRANSMISSION BYTES FOR MECHATRO-LINK-III (P. 4-111)

3-5 Setting the Measurement Cycle



The measurement cycle applies to all channels. This parameter cannot be changed for individual channels.

Select the parameter

azbil Run Ch1 Ch2 Ch3 Ch4

Select 500 or 1000 u, using \bigotimes / \bigotimes .

Parameter	Description	
500.	500 μs	
10000	1 ms	







The selectable measurement cycle varies depending on the length of the junction cable.

7-2 Controllers (P. 7-5)



Save the parameter



Press \bigcup_{Enter} to save it.



The measurement cycle can be changed after the initial setup is completed.

Changing the Measurement Cycle (P. 4-15)

3-6 Receiver adjustment



! Handling Precautions

- · Make sure that there is no workpiece before starting.
- If the laser beam emitting surface or receiving surface is dirty, beam alignment and intensity adjustment cannot be done correctly.
- If the sensor heads are misaligned, moved, or replaced, the sensitivity should be readjusted.



For readjustment, the mode must be switched to Ready. How to switch between Run/Ready modes (P. 4-4)

Select the channel No.

Select the channel No. using O

Display



Run Ch1 Ch2 Ch3 Ch4 Green Red

The number of the selected channel is lit.

2

Adjust the sensor head position

Display (when the K1G-S15 is connected)



– 15 ("07" is displayed when the K1G-S07 is connected)

- See the description below.

During readjustment, display 1 shows the measured value.

The beam is aligned (receiver adjustment is possible).

If the LED bar shown on the left is lit, the receiver can be adjusted. Measurement can begin.
There is a big margin. Receiver adjustment is possible.

The beam is not aligned (receiver adjustment is not possible).

Check the emitter and receiver positions, and the beam angle.

Banne	The light intensity at the receiver is insufficient.
887777	The laser beam is offset to the bottom side (B) of the receiver.
	The laser beam is offset to the top side (T) of the emitter.

During intensity readjustment or a beam alignment check

The upper part of the display shows the lig sity after adjustment.	ght inten-
--	------------

• • •	During receiver adjustment, the light reception indicator works as shown below.			
		Receiver adjustment is	Receiver adjustment	
		possible.	is not possible.	
	Selected channel	Lit	Off	
	Unselected channel	Lit		

Align the beam



3

When the beam is aligned, press \bigcup_{Enter} .

! Handling Precautions

• Beam alignment and intensity adjustment is necessary for every connected channel. Measurement is not possible with unadjusted sensor heads.

4 Complete the adjustments



Press \bigcap_{Run} for at least 3 seconds to end the adjustment.



Choose whether to save the adjustment data



Select whether to save it using @/@.

Parameter	Description	
00	Do not save adjustments	
<i>4E5</i>	Save adjustments.	
965	Save adjustments.	

Note: If "no" is selected, and the power is turned off, the changed parameters will be lost.



Display

6 Start measurement




Press \bigcap_{Enter} to begin measurement.

3-7 Setting the ECAT ID (for K1G-C04EG only)




1 Set the ID using the ECAT ID setting switches



Parameter	Description	
00	ECAT ID is not used	
🛛 / to F F	The set value is used as the ECAT ID	





2 Turn on the power



The setting for the ECAT ID is read only when the power is turned on. Even if the setting is changed during operation, the ECAT ID does not reflect the new setting. To apply a new ID, turn the power off and back on.





ADVANCED SETTINGS

This chapter describes various functions of the K1G series. As needed, the settings should be changed.

4-1	Settings that Can Be Changed
4-2	Changing the Display4-5
4-3	Changing the Measurement Settings4-11
4-4	Changing the Analog Output (AO) Settings4-25
4-5	Using Digital Input (DI) and Digital Output (DO)4-36
4-6	Calculations that Use Measured Data4-61
4-7	Using Special Functions4-76
4-8	Other Functions
4-9	Changing MECHATROLINK-III Communication Settings4-108
4-10	Returning All Settings to the Defaults4-114

In this chapter, the following icons indicate the mode in which settings can be changed.

Ready : Settings can be changed in Ready mode.


Run

: Settings can be changed in Run mode.

4-1 Settings that Can Be Changed

CHANGING THE INITIAL SETTINGS


To change the initial settings configured in chapter 3, see the pages indicated below.



Changing the AO range

- Changing the analog output (AO) range (
- Changing the measurement zero adjustment value . (
- Changing (reversing) the output polarity...... (CP. 4-33)





Enabling disabled functions

ullet Calculations that use measured values of channels (CPP. 4-61)
• Working distance (WD) setting function
• PV hold(CP. 4-79)
• EPS filtering(CP. 4-83)
• Smudge detection (CPP. 4-90)
• Event log function(CP. 4-95)
• Power saving(CP. 4-98)
• Keylock

Other

• Test mode	(🗭 P. 4-96)
• Reverting all settings to the defaults	(CP. 4-114)

HOW TO SWITCH BETWEEN RUN/READY MODES

Ready

Run

• How to check the current mode



To learn the current mode, check the operation indicator. If the LED is lit, the mode is "Run" (measuring).

On the following pages, in order to indicate which mode allows a setting change, one of the following icons is shown for each setting.

: Settings can be changed in Ready mode.

: Settings can be changed in Run mode.

How to switch between modes




Pressing the \bigcup_{Run} key for 3 seconds or more switches between Run and Ready.

Input/output operations in Ready mode.

Analog output (AO): Digital input (DI): Digital output (DO): continues as it was before the mode change. operates when there is input. is forced OFF.

Note: For the K1G-C04MG and K1G-C04EG, network communication (K1G-C04MG: MECHATROLINK-III, K1GC04EG: EtherCAT) is available regardless of whether the device is in Run or Ready mode. However, since the settings might be changed accidentally, keep the controller in Run mode while the equipment is operating.

PARAMETER CONFIGURATION





After switching to another column, the new column's [1] *I*] row is always displayed first. Example: If [71] is displayed and the column is changed to column B, [b1] *I*] is shown.

P. 9-10 (for details)


4-2 Changing the Display

CHANGING THE TYPE OF DISPLAY

The contents of the display while the controller is in Run mode can be selected according to the intended use. There are four display types for the K1G-C04G, and five types for the K1G-C04MG and K1G-C04EG.

Run

Display type	Display 1	Auxiliary display	Display 2
 Standard 	The measured value for the selected channel	Shows which chan- nel's measured value is shown on display 2.	Measured values of channels that are not selected on dis- play 1.
② Received light intensity level	Channels can be switched by pressing ch Select	6 <i>8</i> r	The bar graph shows the intensity of the light received on the selected channel.
③ Peak/bottom value		PE (peak)or とと (bottom)	The peak or bottom value for the se- lected channel
Analog output (AO)		ጸ _ወ <i>ነ</i> Ex.: Channel 1	The analog output value for the se- lected channel
MECHATROLINK-III communication sta- tus check display (for K1G-C04MG only)		Connected) or (not con- nected)	MECHATROLINK-III error status.
6 EtherCAT com- munication sta- tus check display (for K1G-C04EG only)		Indicates the state of EtherCAT com- munication or whether the link to ECAT IN is estab- lished.	Indicates a node ad- dress or whether the link to ECAT OUT is established.



4-2 Changing the Display

1) Standard

Display 1 shows the measured value from the selected channel. The auxiliary display shows the channel number of other channels, and display 2 shows measured values from these channels. If there are several unselected channels, the channels and measured values are

switched automatically every 2 seconds. For the K1G-C04EG, the state of EtherCAT communication is also displayed. The display is the same as that explained in [6], "EtherCAT communication status check display." The display can be switched manually by pressing $\langle \rangle / \langle \rangle$.

If no measurement parameters are assigned to channels other than the selected one: • For the K1G-C04G and K1G-C04MG

The auxiliary display and display 2 show nothing.

· For the K1G-C04EG

The auxiliary display and display 2 show the state of EtherCAT communication.

2 Received light intensity level

Display 1 shows the measured value from the selected channel. The auxiliary display says "*bRr*." The bar graph on Display 2 shows the intensity of light received during measurement.

For the meaning of the bars, 🗭 refer to 3-6, "Receiver adjustment." Note that the intensity of light received cannot be adjusted from this display.

③ Peak/bottom value

Display 1 shows the measured value from the selected channel. The auxiliary display and display 2 show the peak or bottom value. The peak and bottom values can be switched by pressing $\langle \! O \! \rangle / \langle \! D \! \rangle$.

When the auxiliary display says "PE," display 2 shows the peak value. When the auxiliary display says "BE," display 2 shows the bottom value. Pressing \bigcup_{Back} will clear the values.

4 Analog output (AO)

Display 1 shows the measured value from the selected channel. The auxiliary display shows the terminal number of an analog output terminal. While measurement is in progress, display 2 shows the analog output (1.0–5.0 for voltage, 4–20 for current).











⑤ MECHATROLINK-III communication status check display (for K1G-C04MG only)

Display 1 shows the measured value from the selected channel. The auxiliary display shows the connection status of MECHATROLINK-III communication. When connected, " $\mathcal{L} \circ \sigma$ " is displayed. When disconnected, "- - -" is displayed. Display 2 shows the error status of MECHATORLINK-III communication.

For details on the error status, refer to K1G Series High-Accuracy Position Sensor MECHATROLINK-III Communication Manual (No. CP-SP-1386E).

6 EtherCAT communication status check display (for K1G-C04EG only)

Display 1 shows the measured value from the selected channel. The auxiliary display and display 2 show either the EtherCAT status^{*1} or link status.^{*2} Switch between them by pressing $\langle \! \circ \! \rangle / \langle \! \circ \! \rangle$.

*1. EtherCAT status

The auxiliary display shows the status of EtheCAT communication. Display 2 shows the node address.

Auxiliary display	Description	
, ñ	The device is in the Init state.	
Po	The device is in the Pre-Operational state.	
50	The device is in the Safe-Operational state.	
oP	The device is in the Operational state.	
Ein	An error occurred in the Init state.	
EPo	An error occurred in the Pre-Operational state.	
ESo	An error occurred in the Safe-Operational state.	
Eop	An error occurred in the Operational state.	



*2. Link status

The auxiliary display shows whether the link to the RJ45 connector for ECAT IN is established. If the link is established, "Luca" is displayed. If not, "- uca" is displayed.



Display 2 shows whether the link to the RJ45 connector for ECAT OUT is established. If the link is established, "Lout" is displayed. If not, "-out" is displayed.

CHANGING THE DISPLAY RESOLUTION

Changes the display of digits after the decimal point.



The display resolution applies to all channels. This parameter cannot be changed for each channel.

Procedure

Check that the mode is "Ready"

Run Not lit

If "Run" is lit, press \bigcap_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).

ADVANCED SETTINGS

2

Switch to the display for changing settings



Press \bigcirc_{Para} .



Ready

3 Select RG2 (display resolution)



Select RD2 by pressing \otimes .



4-8



Press \bigcup_{Enter} to finalize your selection of $R \square 2$.



Select the parameter

Select one of the following by pressing \otimes / \otimes .

Parameter	Display range [mm] Default setting	
99.9	-99.9 to +99.9	
9 <i>9</i> .99	-99.99 to +99.99	
9.999	-9.999 to +9.999	 ✓
9.9999	0.0000 to 9.9999	



If 4 digits are shown after the decimal point, the display range is 0.0000 to 9.9999.

Note that the analog output (AO) range, and also the digital output (DO) threshold, are not changed automatically.




Finalize your parameter selection



Press \bigcap_{Enter} to finalize your selection.



To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .





Press O .



Start measuring



To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)


8-1

Choose whether to save the parameter



Choose whether to save by pressing

Display



Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.



8-2 Finalize your selection and start measuring



Press \bigcap_{Enter} to finalize your selection and start measuring.

4-3 Changing the Measurement Settings

CHANGING THE MEASUREMENT MODE


The measurement mode can be selected from ten types according to the object type, the application, and the object's direction of approach.


М	easurement mode	Object type	Measurement orientation
1	Edge measure-	Opaque	Тор
2	ment	object	Bottom
3		Transparent	Тор
4		object	Bottom
5	Width measurement	Opaque	-
6	Gap measurement	object	-
7	Edge width mea-	Transparent	Тор
8	surement	object	Bottom
9	Measurement of		Тор
10	second edge		Bottom

Ready


Edge measurement

Determining edge position Transparent







Edge width measurement



Width measurement

Measuring blocked light width






Opaque

Gap measurement


Measuring width of light through gap Opaque objects






Second edge measurement

Sensing the edge's status Transparent





Procedure

Check that the mode is "Ready"

Run Correction Correct

2

Select the channel whose settings will be changed

If "Run" is lit, press \bigcap_{Run} for 3 seconds or longer, and then check



Select the channel No. by pressing

that "Run" is not lit (= Ready mode).

Display

Run Ch1 Ch2 Ch3 Ch4

Green Red The number of the selected channel is lit.

Switch to the display for changing settings



Press \bigcirc_{Para} .



4 Select *b G 2* (measurement mode)

Press D to select $b\mathcal{D}$ *i*, and then press D to select $b\mathcal{D}\mathcal{Z}$.







Select the parameter

Select one of the following by pressing \otimes / \otimes .

Parameter	Measurement mode	Object type	Measurement orientation	Default setting
1	Edge measurement	Opaque object	Тор	~
2			Bottom	
3		Transparent object	Тор	
Ч			Bottom	
5	Width measurement	Opaque object	-	
Б	Gap measurement		-	
٦	Edge width measurement Measurement of second edge	Transparent object	Тор	
8			Bottom	
9			Тор	
10			Bottom	



Finalize your parameter selection



Press \bigcap_{Enter} to finalize your selection.



To change another setting, select the desired item by pressing \otimes/\otimes

or 《/》.





Start measuring

 0
 3
 5
 6
 7
 (1
 3
 4.5
 7
 (1
 3
 4.5
 7
 (1
 3
 4.5
 7
 (1
 3
 4.5
 7
 (1
 3
 4.5
 7
 (1
 3
 4.5
 7
 (1
 3
 4.5
 7
 (1
 3
 4.5
 7
 (1
 3
 4.5
 (1)
 3
 4.5
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 (2)
 <td

To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)


9-1

Choose whether to save the parameter



Choose whether to save by pressing

Display



Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.



9-2 Finalize your selection and start measuring



Press \bigcap_{Enter} to finalize your selection and start measuring.

CHANGING THE MEASUREMENT CYCLE

Ready



The measurement cycle applies to all channels. This parameter cannot be changed for each channel.

Procedure

1 Check that the mode is "Ready"

If "Run" is lit, press \bigcap_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).



Select 🕫 / (measurement cycle)



Press \bigcap_{Para} to select RD *!*.





2

Enter 80 (



Press \bigoplus_{Enter} to finalize your selection.

4 Select the parameter



 \otimes

Select one of the following by pressing \bigotimes / \bigotimes .

Parameter		Description	Default setting	
	500.	500 µs	 ✓ 	
	1000.	1 ms		




5

6

The list of selectable measurement cycles varies depending on the cable length.

7-2 Controllers (P. 7-5)



Press \bigoplus_{Enter} to finalize your selection.



To change another setting, select the desired item by pressing \bigotimes / \bigotimes or \bigotimes / \bigotimes .

Exit the display for changing settings





7 Start measuring



To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)



Choose whether to save the parameter



Choose whether to save by pressing $\sqrt[3]{3}$.			
Parameter	Description		
<i>~ 0</i>	Setting is not saved.		
YES Setting is saved.			
Note: If "no" is selected and the power			

is turned off, the changed parameter will not be saved.



Display

7-2 Finalize your selection and start measuring



CHANGING THE NO. OF MOVING AVERAGES

Ready

A moving average is calculated from the measured data.

If more moving averages are calculated, the measurements become more reliable, but the response becomes slower.

Procedure

Check that the mode is "Ready"

If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).





2 Select the channel whose settings will be changed

Select the channel No. by pressing

Display

Run Ch1 Ch2 Ch3 Ch4

Green Red The number of the selected channel is lit.

3


Switch to the display for changing settings



 \bigcirc









Press D to select D *i*, and then press D to select D *i*.





Enter 603

Press \bigcup_{Enter} to finalize your selection of $b \square \exists$.



7

Set the parameter.




By pressing \otimes / \otimes , select a value from	1-500.
Press $()/()$ to move the cursor to anot	her digit.

Parameter	Display range [mm]	Default setting
1-500	1-500 (in increments of 1)	<u> 54</u>



If the parameter is set to 1, no moving average will be set.







To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .





Start measuring



To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

9-1

Choose whether to save the parameter



Choose whether to save by pressing ()/()

Display

© <i>\`@</i> .	
Parameter	Description
<i>~ 0</i>	Setting is not saved.
4E S	Setting is saved.

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.




9-2 Finalize your selection and start measuring



CHANGING THE EDGE DETECTION THRESHOLD

Ready

The edge detection threshold is used to judge whether or not light is blocked. With the level of incoming light used for intensity adjustment as 100 %, if the amount of received light is less than the edge detection threshold, the light is judged to be blocked.



Received light profile



When the measurement mode ($b \square 2$) is set (\bigcirc P. 4-11), the edge detection threshold is also automatically set.

For basic measurement, it is not necessary to change the edge detection threshold.

- 25 % for opaque objects
- 75 % for transparent objects

Procedure

Check that the mode is "Ready"



If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).



Ch Select

Select the channel No. by pressing

Display

Run Ch1 Ch2 Ch3 Ch4

Green Red The number of the selected channel is lit.



4

5

Switch to the display for changing settings



Press \bigcirc_{Para} .



Select **b**25 (edge detection threshold)



Press to select \square *I*, and then press to select \square *I*.



Enter **b**ជីទ



Press \bigcap_{Enter} to finalize your selection of $b \square 5$.

6 Set the parameter

P



Press 🛞 /	∕⊗ to	select a	a value	from	5 to	95.
-----------	-------	----------	---------	------	------	-----

		Object type		
Parameter	Description	Opaque	Transparent	
		object	object	
5-95	5–95 % (in increments of 1 %)	25	75	

Press ()/() to move the cursor to another digit.



Finalize the parameter value

Press \bigcup_{Enter} to finalize the selected value.



To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .



Exit the display for changing settings



Press \bigcirc_{Back} .

9 Start measuring



To start measuring, press \bigcup_{Bun} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

9-1

Choose whether to save the parameter



Choose whether to save by pressing Display ()/().

©/()).	
Parameter	Description
~0	Setting is not saved.
<i>465</i>	Setting is saved.

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.



9-2 Finalize your selection and start measuring




4-4 Changing the Analog Output (AO) Settings

CHANGING THE ANALOG OUTPUT (AO) RANGE

The analog output range can be changed.

By using this function to narrow the measurement range, it is possible to obtain analog output with better resolution. The AO corresponds to changes in the measured value.



Check that the mode is "Ready"

If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).



2 Select the channel whose settings will be changed



I	Select t	he c	ha	nne	el N	o. b	у рі	ress	ing	
	Ch Select •									

Correspondence of channels and analog outputs

Channel	Analog output
Ch1	A01
Ch2	A02
Ch3	A03
Ch4	A04

Run Ch1 Ch2 Ch3 Ch4

Green Red

The number of the selected channel is lit.

Ready





Press Orara.



4

Select *[| |* (analog output range low limit)



Press (to select $\mathcal{L}\mathcal{D}$ *I*, and then press (to select E 11.



With K1G-S07

6

Enter [/ /

Press \bigoplus_{Enter} to finalize your choice of \mathcal{L} / \mathcal{L}



Set the parameter



By pressing \otimes / \otimes , select a value from - 99.999-99.999.

Sensor heads	Parameter	Description	Default setting
K1G-S07	-99.999-99.999	-99.999 to +99.999 [mm] (in increments of 1 μm)	- 3.500
K1G-S15	-99.999-99.999	–99.999 to +99.999 [mm] (in increments of 1 $\mu\text{m})$	- 7.500

Press @/@ to move the cursor to another digit.

Finalize your parameter selection



Press \bigoplus_{Enter} to finalize your parameter selection.

7



9




Press \bigotimes to select *L* 12.





Press $\underset{\text{Enter}}{\overset{\bigcirc}{\longrightarrow}}$ to finalize your choice of *L* 12.





By pressing \otimes / \otimes , select a value from - 99.999–99.999.

Sensor heads	Parameter	Description	Default setting
K1G-S07	- 99.999-99.999	–99.999 to +99.999 [mm] (in increments of 1 μm)	3.500
K1G-S15	- 99.999-99.999	-99.999 to +99.999 [mm] (in increments of 1 μm)	1.500

Press \bigcirc / \bigcirc to move the cursor to another digit.



Set the parameters such that: $\mathcal{L} + \mathcal{L}$ (low limit) < $\mathcal{L} + \mathcal{L}$ (high limit)

11 Finalize your parameter selection





To change another setting, select the desired item by pressing \bigotimes / \bigotimes or \bigotimes / \bigotimes .

12 Exit the display for changing settings



Press \bigcup_{Back} .

13 Start measuring



To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

13-1 Choose whether to save the parameter



Choose whether to save by pressing ()/()


© <i>\</i> @.	
Parameter	Description
<i>~o</i>	Setting is not saved.
<i>4</i> £5	Setting is saved.

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.



13-2 Finalize your selection and start measuring





After the zero adjustment, change the analog output (AO) range so that the analog output correctly corresponds to the measured value. CP. 4-25

In addition, check the digital output (DO) high and low thresholds.

Procedure



Check that the mode is "Ready"



If "Run" is lit, press \bigcap_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).

2

Select the channel whose settings will be changed

Select the channel No. by pressing



Ch Select

Display



Green Red The number of the selected channel is lit.





Press O .





Select **b 🛛 6** (zero adjustment value)



Press (to select $\square \square$ \square , and then press (to select $\square \square \square$.





Press \bigcup_{Enter} to finalize your choice of BDE.



Set the parameter

Ente

By pressing \otimes / \otimes , select one of the following.

Sensor heads	Parameter	Description	Default setting
K1G-S07	- 3.500-3.500	-3.500 to +3.500 [mm] (in increments of 1 μm)	0.000
K1G-S15	- 1500–1500	-7.500 to +7.500 [mm] (in increments of 1 μm)	0.000

Press ()/() to move the cursor to another digit.




With the K1G-S07, for a measurement range of 0.000–7.000 [mm], set the parameter to 3.500.

7 Finalize your parameter selection



Press \sum_{Enter}^{1} to finalize your parameter selection.





Exit the display for changing settings





Start measuring



To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

9-1

Choose whether to save the parameter



Choose whether to save by pressing @/@.

ParameterDescriptionnoSetting is not saved.¥E5Setting is saved.

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.



Display

9-2 Finalize your selection and start measuring




Ready

SETTING REVERSE POLARITY

The analog output (AO) polarity can be reversed.

AO polarity example (for K1G-S15)



Procedure

Check that the mode is "Ready"



If "Run" is lit, press \bigcap_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).

Select the channel whose settings will be changed

Select the channel No. by pressing



2

Display

🔲 Run Ch1 Ch2 Ch3 Ch4

Green Red The number of the selected channel is lit.





Press O .



4 Select *L I* (analog output reverse polarity)



Press ()) to select $\Box \Box$ *I*, and then press ()) to select \Box *I*.





6



Press \bigoplus_{Enter} to finalize your choice of \mathcal{L} / \mathcal{D} .

Set the parameter



Press \otimes / \otimes to select aFF or an.

	Parameter	Description	Default setting
ļ	oFF	Disabled (positive polarity)	v
-	00	Enabled (negative polarity)	

7 Finalize your parameter selection



Press \bigcap_{Enter} to finalize your parameter selection.



To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .



Exit the display for changing settings





Start measuring



To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

9-1 Choose whether to save the parameter



Choose whether to save by pressing Display

\bigcirc / \oslash .	
Parameter	Description
00	Setting is not saved.
465	Setting is saved.

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.



9-2 Finalize your selection and start measuring



4-5 Using Digital Input (DI) and Digital Output (DO)


CHANGING DIGITAL INPUT (DI) SETTINGS

Up to 4 digital inputs can be used.

Channels and event types can be combined freely.

DI operation type	Operation
Zero adjustment input	When DI is turned ON, the zero point for measurement is changed. (CCC Changing the zero adjustment value (P. 4-29))
Input for cancellation of EPS filter output hold	While DI is ON, EPS filter output hold is canceled. (🗲 Setting EPS filters (P. 4-83))
Input to forcibly cancel EPS filter output hold	When DI is turned ON, EPS filter output hold is forcibly canceled. (🗲 Setting EPS filters (P. 4-83))
Event log start input	When DI is turned ON, the event log function is activated. (Configuring the event log function (P. 4-95))
Input for PV hold	Used for the PV hold function. (🗲 Configuring the PV hold function (P. 4-79))
Laser start input	While DI is ON, the laser beam is emitted. (🗲 9-7 Important Notes for Restarting the Laser Beam (P. 9-31))
Calculation OFF input	While DI is ON, calculation is suspended. Note: While DI is ON, the PV, AO, and DO are not updated.

DI operating conditions



The minimum input time (X ms) varies depending on the selected measurement cycle. 12 ms: when 500 μ s is selected 24 ms: when 1 ms is selected



"PV" refers to the output after calculation.

9-3 Processing Flowchart (P. 9-12)

Procedure

Ready

1

Check that the mode is "Ready"

If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).



2 Select the channel whose settings will be changed



Select the channel No. by pressing
Select the channel No. by pressing

Ch Select	
Channel	Digital input
Ch1	DI1
Ch2	DI2
Ch3	DI3
Ch4	DI4

Display

Run Ch1 Ch2 Ch3 Ch4

Green Red The number of the selected channel is lit.



Switch to the display for changing settings



Press O





Select *EOS* (DI function selection)



Press D to select $\mathcal{E}\mathcal{G}$ *i*, and then press D to select $\mathcal{E}\mathcal{G}\mathcal{G}$.





Select the parameter



6

Press \otimes / \otimes to select one of the following parameters.

	1	JI	
Parameter	Channel	Description	Default setting
D-RdJ	Specified	Zero adjustment input	~
EPS	channel	Input to cancel EPS filter output hold	
PU-h		Input for PV hold	
RLL D-RdJ	All channels	Zero adjustment input	
RLL EPS		Input to cancel EPS filter output hold	
RLL PU-h		Input for PV hold	
RLL F-EPS		Input to forcibly cancel EPS filter output hold	
RLL Ld-on		Laser start input	
RLL do-oF		Calculation OFF input	
RLL LoG		Event log start input	

! Handling Precautions

- When using all-channel EPS filter output hold cancellation input (DI) to cancel the EPS filter on all channels, do not assign EPS hold cancellation input to another DI also.
- When using all-channel PV hold input (DI), do not assign PV hold input to another DI also.
- If the laser start input is assigned to multiple DIs, the laser beam will be emitted only when all of those DIs are ON.
- If calculation OFF input is assigned to multiple DIs, calculation will be stopped if any one of those DIs is ON.

Finalize your parameter selection





To change another setting, select the desired item by pressing \bigotimes / \bigotimes or \bigotimes / \bigotimes .



Exit the display for changing settings





Start measuring



To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)



Choose whether to save the parameter

Choose whether to save by pressing

Description
Setting is not saved.
Setting is saved.

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.



9-2 Finalize your selection and start measuring





DIGITAL OUTPUTS (DO)

Up to 8 digital outputs can be used.

Channels and event types can be combined freely.


Using outputs during measurement






SETTING THE DIGITAL OUTPUT (DO) OPERATION TYPE: HIGH/LOW/PASS/OUT

Configuration flowchart





Procedure

Check that the mode is "Ready"

If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).





Select the digital output (channel) No.



Select the channel No. by pressing

Display

Run Ch1 Ch2 Ch3 Ch4

Green Red The number of the selected channel is lit.

Correspondence of channels and DO numbers

Channel	Selectable digital outputs	
Ch1	DO1	DO2
Ch2	DO3	DO4
Ch3	DO5	DO6
Ch4	DO7	DO8

3

2

Switch to the display for changing settings









Select *E* ^[] *i* or *E* ^[] ^[] 5 (event source)



To select *E □ 1*, press ()) to display *E □ 1*.





To select $E \square 5$, press \bigcirc to select $E \square I$, and then press \bigcirc to display $E \square 5$.



*1. The selected No. is displayed.*2. The selected channel is displayed.

Enter Eû / (or Eû5)

Ente

Press \bigoplus_{Enter} to finalize your choice of *ED !/ED*5.

Select the parameter



 \bigcirc

Select one of the following by pressing \otimes / \otimes .

Parameter	Description
Eoñ	All channels (OR output)
<u>[h 1</u>	Ch1 (for PV1)
Eh2	Ch2 (for PV2)
[h]	Ch3 (for PV3)
[h4	Ch4 (for PV4)

The default selection is the channel selected in step 2 above.

5

6

7 Finalize your parameter selection



 $\mbox{Press} \bigoplus_{\mbox{Enter}}$ to finalize your parameter selection.





Select $E \square 2$ or $E \square B$ (event type)





To select EBE, press 🛞.

press 🛞.



*The selected No. is displayed.

Enter $E \square 2$ (or $E \square B$)



Press \bigoplus_{Enter} to finalize your choice of *E* \square *2* or *E* \square *E*.

10 Select the parameter



Select one of the following by pressing \bigotimes / \bigotimes .

Parameter	Description	Default setting
PRSS	Pass	✔ (E02)
out	Out	🖌 (E05)
<u> </u>	High	
Lo	Low	
EP 5	EPS event	
hold	Holding	
L ,БАЕ	Smudge	
Er iG	Output update	
50 05	Normal operation	

Do not select shaded parameters.





Press \bigcap_{Enter} to finalize your parameter selection.



To use the delay timer, go to step 12. If it is not used, go to step 20 ($rac{rac}{rac}$ P. 4-49).



12 Select *E D 3* or *E D 7* (delay setting)



To select *E □ 3*, press ⊗.

Display



To select *E □* 7, press ⊗.





*The selected No. is displayed.

13 Finalize your parameter selection



Press \bigcap_{Enter} to finalize your parameter selection.

14 Select the parameter



Select one of the following by pressi	llowing by pressing 🔗 /	⊗.
---------------------------------------	-------------------------	----

Parameter		Description	Default setting	
	onE	No timer	v	
0	n-d	ON-delay timer		
0	۶-۵	OFF-delay timer		



Press \bigcap_{Enter} to finalize your parameter selection.



16 Select *E* ^{*D*} ^{*Y*} or *E* ^{*D*} ^{*B*} (delay time)



To select *E □ ч*, press ⊗.

Display



To select E□B, press ⊗.



*The selected No. is displayed.

17 Enter *E* ^{*D*} ^{*Y*} (or *E* ^{*D*} ^{*B*})

5 6 7

Press \bigoplus_{Enter} to finalize your choice of *ED*4 or *ED*8.

18 Select the parameter



Select one of the following by pressing \bigotimes / \bigotimes .

Parameter	Description	Default setting
10	10 ms	
20	20 ms	
30	30 ms	
40	40 ms	V
50	50 ms	
60	60 ms	
סר	70 ms	



Press \bigcap_{Enter} to finalize your parameter selection.



20 Select 207 (low threshold)



Press to select $\pounds \square$ *i*, and then press to select $\pounds \square$ 7.



With K1G-S15 sensor



Press $\underset{\text{Enter}}{\bigcup}$ to finalize your choice of $L \square 7$.



Ente



Enter


By pressing \otimes / \otimes , select a value from -33.333-33.333.

Sensor heads	Parameter	Description	Default setting
K1G-S07	-99.999-99.999	-99.999 to +99.999 [mm] (in increments of 1 μm)	- 3.500
K1G-S15	-99.999-99.999	-99.999 to +99.999 [mm] (in increments of 1 μm)	- 7.500

Press @/ @ to move the cursor to another digit.

23 Finalize your parameter selection






With K1G-S15 sensor



Press \bigoplus_{Enter} to finalize your choice of *LDB*.





By pressing \otimes / \otimes , select a value from -99.999-99.999.


Sensor heads	Parameter	Description	Default setting
K1G-S07	-99.999-99.999	-99.999 to +99.999 [mm] (in increments of 1 μm)	3.500
K1G-S15	-99.999-99.999	-99.999 to +99.999 [mm] (in increments of 1 μm)	7.500

Press @/ @ to move the cursor to another digit.

27 Finalize your parameter selection



 $\mbox{Press} \bigoplus_{\mbox{Enter}}$ to finalize your parameter selection.



28 Select []] (hysteresis)



Press [⊗] to select *L* □ *g*.





Press \bigcap_{Enter} to finalize your choice of *LDB*.

30 Set the parameter



By pressing \bigotimes / \bigotimes , select a value from $\square \square \square \square \square$.

Parameter	Description	Default setting
0.0 10- 1.000	Settable in increments of 1 µm	0.0 10

Press @/ @ to move the cursor to another digit.

31 Finalize your parameter selection



Press \bigoplus_{Enter} to finalize your parameter selection.



To change another setting, select the desired item by pressing \bigotimes / \bigotimes or \bigotimes / \bigotimes .

32 Exit the display for changing settings



Press \bigcup_{Back} .

33 Start measuring




To start measuring, press \bigcup_{Bun} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

ADVANCED SETTINGS



33-1 Choose whether to save the parameter Choose whether to save by pressing Display




Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.






33-2Finalize your selection and start measuring





SETTING SPECIAL OUTPUTS

Configuration flowchart







Check that the mode is "Ready"



If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).



2

Select the digital output (channel) No.



Select the channel No. by pressing

Display

Run Ch1 Ch2 Ch3 Ch4

Green Red The number of the selected channel is lit.

Correspondence of channels and DO numbers

Channel	Selectable digital outputs	
Ch1	DO1	DO2
Ch2	DO3	DO4
Ch3	DO5	DO6
Ch4	DO7	DO8

3 Switch to the display for changing settings



Press \bigcirc_{Para} .









To select $E \square$ *i*, press () to display E 1 1.



*1. The selected No. is displayed. *2. The selected channel is displayed.



To select EBS, press (to select $E \square$ I, and then press (to display EDS.

5

6

4



Press \bigoplus_{Enter} to finalize your choice of *ED !/ED*5.

Select the parameter



Select one of the following by pressing \bigotimes / \bigotimes .

Parameter	Description
Loñ	All channels (OR output)
[h	Ch1 (for PV1)
Eh2	Ch2 (for PV2)
[h]	Ch3 (for PV3)
[h4	Ch4 (for PV4)

The default selection is the channel selected in step 2 above.


7 Finalize your parameter selection



 $\mbox{Press} \bigoplus_{\mbox{Enter}}$ to finalize your parameter selection.



8





To select *E B 2*, press ⊗.





To select E □ E, press ⊗.



*The selected No. is displayed.



Enter *E02* (or *E06*)

Press \bigoplus_{Enter} to finalize your choice of *E* \square *Z* or *E* \square *E*.

10 Select the parameter

Enter



Select one of the following by pressing \otimes / \otimes .


Parameter	Description	Default setting
PRSS	Pass	✓ (E02)
out	Out	✓ (E05)
hi	High	
Lo	Low	
EPS	EPS event	
hold	Holding	
L ,6hE	Smudge	
Er iG	Output update	
60 m6	Normal operation	

Do not select shaded parameters.

11 Finalize your parameter selection



Press \bigoplus_{Enter} to finalize your parameter selection.





12 Select *E D 3* or *E D 7* (delay setting)



To select $\mathcal{E}\mathcal{D}\mathcal{B}$, press \otimes .

Display





To select *E □* 7, press ⊗.



*The selected No. is displayed.

13 Finalize your parameter selection



 $\label{eq:Press} \underset{\text{Enter}}{\bigcirc} \text{ to finalize your parameter selection.}$

14 Select the parameter



Select one of the following b	y pressing 🚳 / 🗞	۵.
-------------------------------	------------------	----

Parameter	Description	Default setting
nonE	No timer	 ✓
on-d	ON-delay timer	
oF-d	OFF-delay timer	

15 Finalize your parameter selection



Press \bigcap_{Enter} to finalize your parameter selection.



4 16 Select ED4 or ED8 (delay time)



To select *E □ ч*, press ⊗.



To select E□B, press ⊗.





*The selected No. is displayed.

17 Enter *E***0***Y* (or *E***0***B*)

Press \bigoplus_{Enter} to finalize your choice of *E* \square *Y* or *E* \square *B*.



18 Select the parameter



Select one of the following by pressing \bigotimes / \bigotimes .

Parameter	Description	Default setting
10	10 ms	
20	20 ms	
30	30 ms	
40	40 ms	 ✓
50	50 ms	
60	60 ms	
סר	70 ms	

19 Finalize your parameter selection



Press \bigcap_{Enter} to finalize your parameter selection.



To change another setting, select the desired item by pressing \bigotimes / \bigotimes or \bigotimes / \bigotimes .

20 Exit the display for changing settings



Press O.

21 Start measuring



To start measuring, press \bigcup_{Bun} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

21-1 Choose whether to save the parameter

9E 5



Choose whether to save by pressing $\langle\!\langle$

Display



©/D.	
Parameter	Description
<i>~0</i>	Setting is not saved.

Setting is saved.

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.




21-2 Finalize your selection and start measuring



Press \bigcap_{Enter} to finalize your selection and start measurina.

OVERVIEW OF CALCULATIONS

The controller can execute various calculations based on the measured data from the channels.



! Handling Precautions

- The following calculations are not possible with a measurement cycle of 250 $\mu s.$ If this speed is specified, the controller will perform no calculation.
 - θ calculation
 - Measurement range expansion calculation



If advanced calculations are used, check the analog output (AO) range and the high and low thresholds for digital output (DO).

SETUP OF THE FOUR ARITHMETIC OPERATIONS

Ready

The basic arithmetic operations can be executed on the measured data from 4 channels after their zero point has been adjusted.

These operations are used for width measurement of a workpiece, averaging of channel data, etc.

The basic arithmetic operations use the following formula:


 $\frac{(K1 \times Ch1 + K2 \times Ch2 + K3 \times Ch3 + K4 \times Ch4)}{C2} + C1$

Ch1-Ch4: Measured values from channels


- K1-K4: Multiplier
- C1: Addition/subtraction parameter
- C2: Division parameter

Parameter samples

Calculating variations in workpiece width using two sensors



Calculating the average of channels 2, 3, and 4 and the difference between the average and channel 1.



Procedure

Check that the mode is "Ready"

If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).





Select the channel whose settings will be changed

Select the channel No. by pressing

Display



Och Select.

Run Ch1 Ch2 Ch3 Ch4

Green Red The number of the selected channel is lit.





If channel 1 is selected, analog output 1 is set.



Switch to the display for changing settings



Press Orara.





Select [] (inter-channel calculation)



Press (1) to select E 🛛 I.





6 Select parameter *F* - *YE h*



Select F - 4Eh by pressing \otimes .

Parameter	Description	Default setting
nonE	Disabled	 ✓
F-4[h	Four arithmetic operations	
F-RoG	θ calculation	
F-EhE	Measurement range expansion	
	calculation	

Do not select shaded parameters.



Finalize your parameter selection




Press $\underset{\text{Enter}}{\bigcirc}$ to finalize your parameter selection.

8 Select d 🛛 (calculation parameter K1)



Press (1) to select d 11 1.





9

Press $\underset{\text{Enter}}{\bigcirc}$ to finalize your choice of $d\square$!.

10 Set the parameter



Set a value from - 1000 - 1000 by pressing \bigotimes / \bigotimes .

ltem	Parameter	Description	Default setting
d0 I	- 1000- 1000	K1: Multiplier for Ch1	1

 \otimes/\otimes to move the

11 Finalize your parameter selection



 $\mathsf{Press} \bigoplus_{\mathsf{Enter}}$ to finalize your parameter selection.

12 Set *d* 02–*d* 06 (calculation parameters K2, K3, K4, C1, C2)



For the setup procedure, see steps 8–11 for $d\square$ 1. In step 8, press \bigotimes to select $d\square 2 - d\square 5$.

Item	Parameter	Description	Default setting
202	- 1000- 1000	K2: Multiplier for Ch2	1
603	- 1000- 1000	K3: Multiplier for Ch3	1
<i>404</i>	- 1000- 1000	K4: Multiplier for Ch4	1
d05	- 9.999-9.999	C1: Addition-subtraction parameter	0.000
406	I- I0000	C2: Division parameter	ч



To change another setting, select the desired item by pressing \bigotimes / \bigotimes or @/@.

13 Exit the display for changing settings




Press Or .





To start measuring, press \bigcup_{Bun} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)



Choose whether to save by pressing Display @//@

Parameter	Description
<i>~ 0</i>	Setting is not saved.
4E S	Setting is saved.


Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.





14-2 Finalize your selection and start measuring





SETUP OF O CALCULATION

Ready

The tilt angle (θ) of the edge is calculated from edge position measurement by sensor heads on two channels.

 θ calculation can be done with channels 1 and 2 or with channels 3 and 4. θ calculation uses the following formula:


Channels 1 and 2

$$\theta = K1 \times \frac{180}{\pi} \times \tan^{-1} \left(\frac{Ch1 - Ch2}{C2} \right)$$

Ch1, Ch2: Measured values

K1: Multiplier for angle

C2: Distance between channel 1 and 2 sensors



Procedure

Check that the mode is "Ready"

If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).





2 Select the channel whose settings will be changed



Select the channel No. by pressing

Display

Green Red

The number of the selected channel is lit.



This function can be used for channels 2 and 4 only. If channel 1 or 3 is selected, nothing is displayed for the parameter setting.



4

5

Switch to the display for changing settings







4

Select [] / (inter-channel calculation)



Press (1) to select [] 1.



Enter £ 0 f

Press Enter to finalize your choice of $\operatorname{E} \operatorname{I}$!.

6 Select parameter *F* - *R*₀*G*



Select $F - R \cap G$ by pressing \otimes / \otimes .

Parameter	Description	Default setting
nonE	Disabled	 ✓
F-4Eh	Four arithmetic operations	
F-8-5	θ calculation (channels 2 or 4 only can be selected)	
F-EHE	Measurement range expansion calculation	

Do not select shaded parameters.



Enter parameter F - RoG



Press \bigoplus_{Enter} to finalize your parameter selection.



Select *d* ^[] *i* (calculation parameter K1)



Press (1) to select d 1 1.





Enter d 🛛 🕴



Press \bigoplus_{Enter} to finalize your choice of $d\mathcal{D}$!.

10 Set the parameter



Set a value from - 1000 - 1000 by pressing \bigotimes / \bigotimes . Press ()/() to move the cursor to another digit.

Item	Parameter	Description	Default setting
d0 (- 1000- 1000	K1: Multiplier parameter for angle	1

11 Finalize your parameter selection



Press Enter to save it.



12 Set *d* **D** *E* (calculation parameter C2)



For the setup procedure, see steps 8–11 for $d\Box$ 1. In step 8, press ⊗ to select d□5.

ltem	Parameter	Description	Default setting
406	I- 10000	C2: Distance between sensors	ч



To change another setting, select the desired item by pressing \bigotimes / \bigotimes or $\langle \rangle \rangle$.

13 Exit the display for changing settings



Press \bigcap_{Back} .

14 Start measuring



To start measuring, press \bigcup_{Bun} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

14-1 Choose whether to save the parameter

Parameter


no



Choose whether to save by pressing ()/().

Description Setting is not saved. Display

_





14-2 Finalize your selection and start measuring




Press \bigcap_{Enter} to finalize your selection and start measuring.

SETTING THE MEASUREMENT RANGE EXPANSION CALCULATION

Ready

Output to expand the measurement range is calculated from edge position measurements by two pairs of sensor heads. This function is used for measuring a width of 15 mm or more.

The measurement range expansion calculation can be done using channels 1 & 2 or using channels 3 & 4.



After installation of the sensor heads, executing zero adjustment for both channels is necessary to set the zero points for measurement. CP Changing the zero adjustment value (P. 4-29)

Procedure

Check that the mode is "Ready"



If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).

2

Select the channel whose settings will be changed

DOLIZIAS 07 8 LILIA Ban © D Enter © Bac Ch Select

Select the channel No. by pressing

Ch Select

Display

□ Run Ch1 Ch2 Ch3 Ch4

Green Red The number of the selected channel is lit.



This function uses channels 2 or 4 only. If channel 1 or 3 is selected, nothing is displayed for the parameter setting.



Switch to the display for changing settings







5

Select [] / (inter-channel calculation)



Press (1) to select [] 1.





] /

Press $\underbrace{\mathsf{Enter}}_{\mathsf{Enter}}$ to finalize your choice of $\mathsf{L} \, \mathsf{I}$!.

6 Select parameter *F* - *EHE*



Select F - E H E	by pressing \otimes / \otimes .
------------------	-----------------------------------

Parameter	Description	Default setting
nonE	Disabled	 ✓
F - 4Ch Four arithmetic operations		
$F - B \cap G$ θ calculation		
F - EHE Measurement range expansion calculation (channels 2 or 4 only can be selected)		

Do not select shaded parameters.





Press \bigoplus_{Enter} to finalize your selection.



To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .



Exit the display for changing settings





9 Start measuring



To start measuring, press \bigcup_{Bun} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)



Choose whether to save the parameter



Choose whether to save by pressing $@/@$.			
Parameter Description			
Setting is not saved.			
Setting is saved.			
Note: If "no" is selected and the power			

is turned off, the changed parameter will not be saved.



9-2 Finalize your selection and start measuring




Press \bigcap_{Enter} to finalize your selection and start measuring.

4-7 Using Special Functions

SETTING A WORKING DISTANCE (WD)

Ready

This function can be used for future K1G products. It will not improve the accuracy of position measurement if it is used with model K1G-S07 or K1G-S15.



2 Select the channel whose settings will be changed



Select the channel No. by pressing

Display

Run Ch1 Ch2 Ch3 Ch4

Red Green The number of the selected channel is lit.

3





Press \bigcup_{Para} .

Ch Select



4 Select **b D ?** (working distance)



Press D to select D *I*, and then press D to select D *I*.







Press \bigoplus_{Enter} to finalize your choice of $B \square 7$.



Set the parameter



Set one of the following by pressing \otimes / \otimes .

Sensor head	Parameter	Description	Default setting
All models	0-9	Disabled	0
K1G-S07	10-500	10–500 [mm] (set in increments of 1 mm)	-
K1G-S15	10-1500	10–1500 [mm] (set in increments of 1 mm)	-

7 Finalize your parameter selection



Press \bigcap_{Enter} to finalize your parameter selection.



To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .



Exit the display for changing settings

Press O.





Start measuring



To start measuring, press \bigcup_{Run} for 3 seconds or longer.



9-1 Choose whether to save the parameter



Choose whether to save by pressing Display ()

Parameter	Description			
<i>~ 0</i>	Setting is not saved.			
<i>4</i> 25	Setting is saved.			

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.





9-2 Finalize your selection and start measuring



Press \bigcap_{Enter} to finalize your selection and start measuring.

CONFIGURING THE PV HOLD FUNCTION

Ready


When the PV hold input is set for a digital input (DI), if the digital input is ON, the PV is held at the maximum (or minimum) value whenever it is updated.

If the digital input (DI) turns OFF, the maximum (or minimum) PV will no longer be updated, but the PV will continue to be held until the input turns ON again.

! Handling Precautions

• During initialization, for example, after the power is turned on, the PV is held at 0. If this will cause a problem, cancel the hold status using the host controller.

Example of operation when digital input (DI) maximum hold is selected



Procedure



Check that the mode is "Ready"



If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).

2

Select the channel whose settings will be changed



Select the channel No. by pressing

Display

Green Red The number of the selected

The number of the selected channel is lit.



4 Select *C D 2* (hold setting)



Press D to select $\pounds \square$ *i*, and then press D to select $\pounds \square 2$.



Enter []2



Press \bigoplus_{Enter} to finalize your choice of $L \square 2$.

6 Select the parameter



Select one of the following by pressing \otimes / \otimes . Default Description Parameter setting Disabled nonE V PU-hI Digital input (DI) max. value hold function PU-h2 Digital input (DI) min. value hold function EPS-1 **EPS filter 1** EP5-2 EPS filter 2 EPS-3 **EPS filter 3** EPS filter 4 EPS-4 EP5-5 EPS filter 5

Do not select shaded parameters.

5





Press \bigoplus_{Enter} to finalize your parameter selection.



To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .



Exit the display for changing settings

Press \bigcup_{Back} .

(





Start measuring





To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)



Choose whether to save the parameter





Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.







 $\ensuremath{\mathsf{Press}}\xspace \sum_{\ensuremath{\mathsf{Enter}}\xspace}$ to finalize your selection and start measuring.




SETTING EPS FILTERS

Ready

If there is a sudden change in the position of a workpiece's edge, an EPS filter can cope with this change by holding the output steady to prevent a change in the PV and analog output.

Five types of ESP filter are selectable to suit various purposes.



EPS filter 1

With zero change in the measured value as a basis, if the measured value exceeds the skip-over size, the output will be held.

If the measured value returns to the skip-over size or less, output will not be held. EPS filter 1 does not use the number of delays.


The hold state can be canceled by pressing the B key on the controller.

EPS filters 2–5

If there is a sudden change in the position of the edge, the output is held steady. The conditions for holding the output are configured using the number of delays and the skip-over size. If the measured value exceeds the skip-over size within the delay time (= measurement cycle × number of delays), the output is held steady. The cancellation timing and conditions are shown below.

Filter name	Cancellation timing	Cancellation conditions	
EPS filter 2 When a fixed period (4 times the delay time) has passed.		When the held value and the actual value after the delay are compared, the difference is less than the skip-over size.	
EPS filter 3		The hold status is canceled re- gardless of the measured value.	
EPS filter 4	When the EPS hold cancellation input set for the digital input (DI) is	When the skip-over size is no longer exceeded	
EPS filter 5	turned ON	The hold status is canceled re- gardless of the measured value.	
All filters	When the B key on the controller is pressed.	The hold status is canceled re- gardless of the measured value.	
	When the EPS hold forced cancel- lation input set for the digital input (DI) is turned ON		

Setup example for EPS filters 2–5



Calculate the time it takes for something that should be ignored to pass by

v = 6 m/min = 100 mm/s Passing time = w/v = 2/100 = **20 ms**

2 Set the number of delays (*C I 3*: No. of EPS filter delays)

For the delay time, use about half of the passing time calculated in step **1** as a rough estimate.

Delay time = Measurement cycle \times No. of delays

Measurement cycle (RD /)	No. of delays (rough estimate)
500 µs	20
1 ms	10

3


Set the skip-over size (*L 🛛* 4: EPS filter size)

Set it using about half of the length (h) as a rough estimate. Length of the target to ignore = 3.0 mm Skip-over size = **1.5 mm**



Set the skip-over direction (*E* 25: EPS filter direction)

Select *d r a P* (concave direction).



Select an (enabled).

Procedure

Ready

1

Check that the mode is "Ready"

If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).



2

Select the channel whose settings will be changed



Select the channel No. by pressing

Ch Select

Display

Run <u>Ch1</u> Ch2 Ch3 Ch4

Green Red The number of the selected channel is lit.





4

Switch to the display for changing settings



Press Oraca.

Display



Select []]? (hold setting)



Press D to select $\Box \Box$ *i*, and then press D to select $\Box \Box Z$.





6 Select the parameter



Select the parameter by pressing	$\otimes / \otimes_{.}$
----------------------------------	-------------------------

Parameter	Description	Default setting
nonE	Disabled	v
РU-н (Digital input (DI) max. value hold function	
PU-h2	Digital input (DI) min. value hold function	
EP5-1	EPS filter 1	
EP5-2	EPS filter 2	
EP5-3	EPS filter 3	
EP5-4	EPS filter 4	
EP5-5	EPS filter 5	

Do not select shaded parameters.

7 Finalize your parameter selection



Press $\underset{\text{Enter}}{\bigcirc}$ to finalize your parameter selection.

8

Select []] (No. of EPS filter delays)



Press (to select \square \square \square , and then press (to select \square \square .



9 Set the parameter



Select one from l-256 by pressing \otimes / \otimes .

	Parameter	Description	Default setting
ļ	1-256	1-256 (times)	1

10 Finalize your parameter selection



Press \bigoplus_{Enter} to finalize your parameter selection.

11 Set *E B 4 – E B 5* (EPS filter size / EPS filter direction / EPS filter output hold)

For the setup procedure, see steps 8–10 for $\square \square$. In step 8, press to select $\square \square \square \square$.

C 입 식: EPS filter size (skip-over size)

Parameter	Description	Default setting
0. 100-50.000	0.1–50.000 [mm]	0. 100

*CG***5**: EPS filter direction (skip-over direction)

Parameter	Description	Default setting
both	Concave and convex	 ✓
r iSE	Convex	
droP	Concave	

۲۵۵: EPS filter output hold (enabled/disabled)

Parameter	Description	Default setting
oFF	Disabled	
00	Enabled	 ✓

12 Finalize your parameter selection



Press \bigoplus_{Enter} to finalize your parameter selection.



To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .

13 Exit the display for changing settings



Press \bigcirc_{Back} .

(




14 Start measuring




To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

14-1 Choose whether to save the parameter





Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.





14-2 Finalize your selection and start measuring



Press \bigcap_{Enter} to finalize your selection and start measuring.


CHANGING SMUDGE DETECTION FUNCTION SETTINGS

Ready


A change in the amount of received light caused by a smudge (foreign matter) on the sensing surface or interference from ambient light can be detected and sent to the host device. The light intensity change rate calculated by the following formula is used as an index that indicates the significance of the effect from a smudge or interference from ambient light.

Light intensity change rate = $(S2/S1) \times 100$

S1 is the total light intensity estimated from the edge position and S2 is the total light intensity in the profile of received light.



If there is a shadow in the profile of received light due to a smudge on the light-receiving surface, S2 will decrease, and thus the light intensity change rate will be lower.



A decrease in total light intensity caused by a smudge

To enable the smudge detection function, set the smudge detection threshold to 1 to 100 %. If the light intensity change rate of 100 % shifts by an amount that is more than the smudge detection threshold, the controller judges that there is a smudge. If the smudge detection threshold is set to 0 %, this function will be disabled. In this case, regardless of the amount of light received, the controller will not detect a smudge.

4

Example of smudge detection: If the smudge detection threshold is set to 20 %



! Handling Precautions

- This function is available if a measurement mode for opaque objects is selected.
- If the gap for entry of light is not wide enough, smudge detection will be unreliable. Under the following conditions, regardless of light intensity, "smudge detected" events will be forcibly cleared.

Measurement mode	K1G-S07	K1G-S15
Opaque object edge position (top)	The edge position is less than 1.5 mm from the bottom.	The edge position is less than 2.0 mm from the bottom.
Opaque object edge measurement (bottom)	The edge position is less than 1.5 mm from the top.	The edge position is less than 2.0 mm from the top.
Opaque object width measurement	The width of blocked light is greater than 4 mm.	The width of blocked light is greater than 11 mm.
Opaque object gap measurement	The gap for entry of light is less than 1.5 mm.	The gap for entry of light is less than 2.0 mm.

Setting the smudge detection threshold to 10 % or greater is recommended. Setting a smaller threshold will make detection of a slight smudge possible, but false detection could result depending on the measurement environment. Check the operation with the actual device and specify an appropriate value.

Procedure

Check that the mode is "Ready"

If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).



2 Select the channel whose settings will be changed



Select the channel No. by pressing

Display

Ch Select •

Run Ch1 Ch2 Ch3 Ch4

Green Red The number of the selected channel is lit.

4

Switch to the display for changing settings



Press Orara .





3

Select **b G Y** (smudge detection threshold)



Press D to select \square *I*, and then press D to select \square *I*.



5 Enter **b**^D**4**



Press \bigoplus_{Enter} to finalize your choice of BDA.

Digital output (DO) must be configured in order to use the smudge detection function. CP P. 4-41

6 Set the parameter

Ente




Set one of th	e following by	v pressing	\otimes / \otimes .

Parameter	Description	Default setting
0	Disabled	~
1- 100	1–100 % (set in increments of 1 %)	

7

Finalize your parameter selection





To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .



Exit the display for changing settings



Press \bigcup_{Back} .

9 Start measuring



To start measuring, press \bigcup_{Bun} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

9-1

Choose whether to save the parameter



Ρ

Choose whether to save by pressing Display ()/().

)/()).	
arameter	Description
<i>~ 0</i>	Setting is not saved.
<i>4</i> £5	Setting is saved.

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.





C

9-2 Finalize your selection and start measuring




Press \bigcap_{Enter} to finalize your selection and start measuring.

CONFIGURING THE EVENT LOG FUNCTION

The event log function, triggered when the specified trigger signal turns ON, saves a received light profile for the selected single channel (normalized light intensities) and the process values from all channels (32×4 channels) to the controller.

To check the event log settings and saved data, the K1G configuration tool or the communication function is used.



The event log records only the log data from the first occurrence of the event. Later occurrences of the event are ignored.

If one of the settings related to the event log is changed by a host device, the event log will be cleared.

ltem	Explanation	Setting method
Trigger signal	Selects the DI operation type used as the trigger signal.	SZ-D01 configuration tool or by communica-
Trigger target	Select the channel of the trigger.	tion
Trigger type	Select the type of event that will act as the trigger.	
Capture channel	Select the source channel for the re- ceived light profile.	
Event log point	Select the ratio of process values to obtain before and after the trigger.	

4-8 Other Functions

TEST MODE



After power-on and after the initial setup is complete, the wiring can be checked by using analog and digital output.



Check that the mode is "Ready"

Contraction of the contraction o

If "Run" is lit, press \bigcap_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).

Press the [Para] and [Back] keys for at least 3 seconds at the same time



Press \bigcap_{Para} and \bigcap_{Back} for at least 3

seconds at the same time.



* The analog output type selected at the initial setup is displayed.

3

2



Analog output check

£E5£ 1) UL E -+ Ro 1 E



* The analog and digital output types selected at the initial setup are displayed.

4 Check the wiring



Check analog output (AO). Change the analog output status for the selected channel by pressing \bigotimes / \bigotimes .

Change the analog output number by pressing O



- *1. The output method is displayed.
 - ULE: Voltage output
 - Lur: Current output
- *2. The analog output status is displayed.
 - *Ro_h*: 5 V or 20 mA
 - Ro_E: 3 V or 12 mA
 - *Ro_L*:1V or 4 mA
 - "_" represents the selected channel No.



Check digital output (DO).

Change the digital output status for the se-

lected No. by pressing \otimes / \otimes .



- *1. The output type is displayed.
 - PoP: NPN output
- *2. The digital output status is displayed.
 - do I-do8: Digital output Nos.
 - RLL: All outputs are ON
 - ---: All outputs are OFF


5 Quit the test mode



Press \bigcup_{Back} to exit.

SAVING ELECTRICITY

Ready



In power-saving mode, the sensor heads and controller each reduce current consumption.

Sensor heads: The light reception indicator only is turned

off while power-saving mode is enabled. In this case, the indicator is also not lit during receiver adjustment.

Controller:

After the power-saving mode is enabled, if there is no key operation for 20 seconds or longer in Run mode, power saving mode is applied automatically. In power-saving mode, all indicators are off except those that are shown as lit in the figure on the left. Pressing any key temporarily cancels powersaving mode.

Procedure

Check that the mode is "Ready"



If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).

2

Switch to the display for changing settings





3

Select RDY (controller power-saving mode) and *R*^{*I*}^{*I*}^{*S*} (sensor head power-saving mode)



For the controller Press ⊗ to select *R*□*Y*.



For the sensor heads Press \otimes to select *RD*5.





Enter ROY/ROS

Press \bigoplus_{Enter} to finalize your choice of RD4 or RD5.



4

Select the parameter



Select ρFF or $\rho \sigma$ by pressing \otimes / \otimes .

Parameter	Description	Default setting
oFF	Power-saving mode disabled	~
00	Power-saving mode enabled	



Finalize your parameter selection



Press \bigcap_{enter} to finalize your parameter selection.



To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .

7





Start measuring



To start measuring, press \bigcup_{Run} for 3 seconds or longer.



(The following procedure is followed if a parameter has been changed.)



Choose whether to save the parameter



Choose whether to save by pressing	Display
©/>.	

Parameter	Description
<i>~o</i>	Setting is not saved.
<i>4</i> £5	Setting is saved.

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.





8-2 Finalize your selection and start measuring



Press \bigcap_{Enter} to finalize your selection and start measuring.



Transition to power-saving mode

If no key is pressed for 20 seconds or longer, power-saving mode goes into effect automatically.

4

CONFIGURING THE KEY LOCK

Ready

This function prevents wrong settings due to key operation by disabling all keys on the controller in Run mode.

The key lock goes into effect 60 seconds after the mode has been switched to Run.



The key lock setting applies to all channels. This parameter cannot be changed for individual channels.

Procedure

Check that the mode is "Ready"



If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).



Switch to the display for changing settings



Press Orara.



3 Select *R***03** (key lock)



Press ⊗ to select 𝕫𝔅 𝔅.







Press Enter to finalize your choice of RD3.



Select the parameter

Select ${}_{o}FF$ or ${}_{o}{}_{o}$ by pressing \otimes / \otimes .

Parameter	Description	Default setting
oFF	Key lock disabled	v
00	Key lock enabled	




Finalize your parameter selection



Press \bigoplus_{Enter} to finalize your parameter selection.



To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .





Press Or .



Start measuring

 Diamage
 3 4 5 6 7 8 (1 ± 3 4 £8)

 Oil
 Oil

 Oil
 Oil

 Oil
 Oil

 Oil
 Oil

 Para
 Oil

 Oil
 Oil

 <

To start measuring, press \bigcup_{Bun} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

8-1

Choose whether to save the parameter



Choose whether to save by pressing ()

Display

\bigcirc / \oslash .	
Parameter	Description
<u>^o</u>	Setting is not saved.
<i>4</i> £5	Setting is saved.

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.



8-2 Finalize your selection and start measuring



Press \bigcap_{Enter} to finalize your selection and start measuring.

CANCELING THE KEY LOCK

Ready

Procedure

Canceling the key lock temporarily

Press 🛞 for at least 2 seconds while pressing







The key lock will go into effect again in 60 seconds.

If necessary, disable it by changing the parameter to "Key lock disabled."

4


RESETTING WHEN CHANGING THE SENSOR HEADS

After the initial setup is complete, in order to switch to a different sensor head model it is necessary to reset the sensor head settings.

Procedure



Check that the sensor connection indicator of the channel whose sensor heads have been replaced is blinking





If a reset of the sensor head settings is needed, the sensor connection indicator blinks and display 2 shows - - - - .

2

Check that the mode is "Ready"



If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).

3 Select the channel to be reset

Select the channel No. by pressing



Press the [Para] and [Enter] keys at the same time for at least 3 seconds



Press \bigcap_{Para} and \bigcap_{Enter} for at least 3 seconds at the same time.



Check that the sensor connection indicator of the channel whose sensor heads have been replaced is lit



After the resetting, adjust the receiver.

After receiver adjustment, the following parameters must be reset.

P. 4-29

C P. 4-42

C P. 4-42

- Zero adjustment value [606]
- Working distance (WD) [5 27]
- Low threshold [[2]]
- High threshold [[08]
- Analog output range low limit [[+ 1] P. 4-25
- Analog output range high limit [[12] 🖒 P. 4-25

SETTING THE STATION ADDRESS FOR MECHATROLINK-III

Procedure

1

 \mathbf{Z}

Check that the mode is "Ready"



If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).





Press Orara.



3 Select RDS



Press ⊗ to select *R*□9.





Press Enter to finalize your choice of RIII.

5 Set the parameter

Enter

Parameter	Description	Default setting
3h-EFh	3 - 239	ЗҺ




4

Finalize your parameter selection

Press \bigoplus_{Enter} to finalize your parameter selection.



To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .







Start measuring

(്ത

To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

8-1

Choose whether to save the parameter



Choose whether to save by pressing @1@

Display

Parameter	Description	
<i>~ 0</i>	Setting is not saved.	
<i>465</i>	Setting is saved.	

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.



8-2 Finalize your selection and start measuring



Press _____ to finalize your selection and start measurina.

SETTING THE NUMBER OF TRANSMISSION BYTES FOR MECHATROLINK-III

Procedure

Check that the mode is "Ready"

If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).





1

Switch to the display for changing settings



Press Orara.





3 so

Select # /0




Press ⊗ to select *R I*.







Enter



4-111

5 Set the parameter

Run C D Enter
Para Stack
ChSelect A B LOADER

Select one of the following by pressing

⊗/⊗.Parameter Description Default setting

32	32 transmission bytes	
48	48 transmission bytes	~



For the number of transmission bytes, see user's manual No. CP-SP-1386E..



7

Finalize your parameter selection



Press \bigoplus_{Enter} to finalize your parameter selection.



To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .

Exit the display for changing settings







Start measuring



To start measuring, press \bigcup_{Bun} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)



Choose whether to save the parameter



\otimes/\otimes .		
Parameter Description		
Setting is not saved.		
YES Setting is saved.		
Note: If "no" is selected and the power		

Choose whether to save by pressing

is turned off, the changed parameter will not be saved.



8-2 Finalize your selection and start measuring



Press \bigcap_{Enter} to finalize your selection and start measuring.

4-10 Returning All Settings to the Defaults

! Handling Precautions

• All settings will be cleared and returned to the defaults.



1

Restore all default settings



While \bigcup_{Run} and \bigcup_{Enter} are being pressed at the same time, turn the power on.



Do the initial setup again. For more information on the initial setup, see the following.

Pinitial Setup Flowchart (P. 3-2)

COMMUNICATION SETTINGS (CONNECTION TO OTHER DEVICES)



	This chapter describes RS-485 communications (Modbus/RTU) with other devices.
	For connection to MECHATROLINK-III, see User's Manual No. CP-SP-1386E.
	For connection to EtherCAT, see user's manual No. CP-SP-1419E.
5-1	Overview of Communications5-2
5-2	Changing the Communications Conditions5-4
5-3	Message Format5-13


5-1 Overview of Communications

This device is compatible with RS-485 and can communicate with host devices such as a PC or PLC using a user-created communications program.

Reading and writing of most parameters between the master station and the controller can be done through communication.

- Communication protocol: Modbus/RTU
- No. of connectable controllers: Up to 15 K1G controllers can be connected to a single master station.

RS-485 communications



15 max.

SETTINGS

For Modbus communication, configure the following in advance.

Description	Parameter	Default setting
Station address	D: No communication D- 12	0
Transmission speed	9.5: 9600 bps 19.2: 9200 bps 38.4: 38,400 bps 1: 15.2: 115,200 bps	5.6
Parity, stop bits P. 5-10	EUEn: Even parity (2 stop bits) EUEn: Even parity (1 stop bit) edd: Odd parity (1 stop bit)	nonE

COMMUNICATION PROCEDURE

- An instruction message is sent from the host device (master station) to the desired single controller (slave station).
- 2 The K1G controller (slave station) reads or writes data in accordance with the instruction message.
- **3** The K1G controller (slave station) sends back a response message related to the requested processing.
- **4** The master station receives the response message.

! Handling Precautions

 In the case of Modbus communications, the communications address (parameter) to the controller set on the host device may change to [address – 1] in a message.
 Example: If the communication address (parameter) is set to 1001 on the host device, it changes to 1000 in the message.

The K1G controller sends/receives messages to/from specified communication addresses (parameters).

Take the host device's specifications into account when using the controller.

SETTING THE STATION ADDRESS

Procedure

1

Check that the mode is "Ready"

If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).





Switch to the display for changing settings



Press Orara.





Select 888



Press ⊗ to select RDE.










Set the parameter



By pressing \bigotimes / \bigotimes , select a value from 0–127.

111			
	Parameter	Description	Default setting
J	0- I2 T	0–127 (0: Communication is disabled)	0



Press \bigoplus_{Enter} to finalize your selection.



To change another setting, select the desired item by pressing \otimes/\otimes or @/》.







Start measuring

O Run ്ത (\odot

To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

8-1

Choose whether to save the parameter



Choose whether to save by pressing @10

Display

© <i>1 @</i> .		
Parameter	Description	
<i>~ 0</i>	Setting is not saved.	
<i>4</i> 85	Setting is saved.	

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.



8-2 Finalize your selection and start measuring



 $\label{eq:press} \underset{\text{Enter}}{\bigcirc} \text{to finalize your selection and start mea-}$ suring.

SETTING THE TRANSMISSION SPEED

Procedure

Check that the mode is "Ready"

If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).





Switch to the display for changing settings



Press \bigcirc_{Para} .





Select RD 7



Press ⊗ to select *R*□7.









Press Enter to finalize your choice of $R \square 7$.

5

Select the parameter



@

Enter

Select one of the following by pressing 🖄)/	\otimes	
---	----	-----------	--

	Parameter	Description	Default setting
J	<u>9.</u> 6	9600 bps	 ✓
-	19.2	19200 bps	
	3 <i>8</i> .4	38,400 bps	
	1 15.2	115,200 bps	



Finalize your parameter selection

Press \bigcup_{Enter} to finalize your parameter selection.



To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .

Exit the display for changing settings



Press \bigcirc_{Back} .

8

Start measuring



To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)



Choose whether to save the parameter



Choose whether to save by pressing	
《 / 》 .	_
$\bigcirc / @.$	

Parameter	Description
<i>~o</i>	Setting is not saved.
<i>4</i> £5	Setting is saved.

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.



8-2 Finalize your selection and start measuring



Press \bigcap_{Enter} to finalize your selection and start measuring.

SETTING THE COMMUNICATIONS FORMAT (PARITY AND STOP BITS)



1

Check that the mode is "Ready"



If "Run" is lit, press \bigcup_{Run} for 3 seconds or longer, and then check that "Run" is not lit (= Ready mode).



Switch to the display for changing settings



Press Orara .



3





Press ⊗ to select *R*□₿.

Display





5 Select the parameter

DO 1 2 3 CONTRACTOR

Ente

Select one of the following	by pressing (⊘/⊗.
-----------------------------	---------------	------

Parameter	Description	Default setting
nonE	No parity (2 stop bits)	~
EUEn	Even parity (1 stop bit)	
odd	Odd parity (1 stop bit)	



Finalize your parameter selection

 $\label{eq:Press} \underset{\text{Enter}}{\bigcirc} \text{ to finalize your parameter selection.}$



To change another setting, select the desired item by pressing \otimes / \otimes or \otimes / \otimes .



Exit the display for changing settings



Press \bigcirc_{Back} .

8 Start measuring



To start measuring, press \bigcup_{Run} for 3 seconds or longer.

(The following procedure is followed if a parameter has been changed.)

8-1

Choose whether to save the parameter



Choose whether to save by pressing Display

©/D.	
Parameter	Description
<i>~ 0</i>	Setting is not saved.
<i>465</i>	Setting is saved.
-	

Note: If "no" is selected and the power is turned off, the changed parameter will not be saved.





8-2 Finalize your selection and start measuring



Press \bigcap_{Enter} to finalize your selection and start measuring.

5-3 Message Format

All messages use binary data.

A Modbus/RTU message consists of (1)–(5) below.

(5)	(1)	(2)	(3)	(4)	(5)
Start	1 byte	1 byte	n bytes (1 byte or more)	2 bytes	End

(1) Station address

The K1G controller creates a response message only if its station address is in the received message. In the message, the station address is 1 byte.

However, if the station address is 0, even if the addresses match, there is no response to the message.

In its response, the K1G controller returns the same station address as that in the received message.

(2) Function codes

The K1G controller then executes the processing indicated by the received function code.

If processing is successfully completed, the received function code will be returned. If processing is not successfully completed and a response indicating an error is returned, the MSB* of the received function code will be set to "1" and returned. *Most significant bit

(3) Data

Data corresponding to the function code is added.

The data types handled by this controller are 16-bit data (2 bytes) and 32-bit data (4 bytes).

The data size of an address is 16 bits. In the case of 32-bit data, 2 addresses compose one data record.

Data format

16-bit data (2 bytes)

The first 8 bits are assigned to the first byte and the last 8 bits to the last byte.

Byte	Data (hex)	Description
1st	12	First 8 bits of data
2nd	34	Last 8 bits of data

Example: If the 16-bit data is 1234

• 32-bit data (4 bytes)

The last16 bits are assigned to the address with the smaller number and the first 16 bits to the address with the larger number.

The byte data order for each address is the same as that of 16-bit data.

Example: If the 32-bit data is 12345678 (addresses 0000-0001)

Address (HEX)	Data (HEX)	Description	Byte	Data (HEX)	Description
	5678	Least 1 Chite of data	1st	56	First 8 bits of address 0000
0000	5678 Last 16 bits of data	2nd 78	Last 16 bits of data	Last to bits of data	Last 8 bits of address 0000
0001	1224	First 16 bits of data	3rd	12	First 8 bits of address 0001
0001 12	1234 First 16 bits of data	4th	34	Last 8 bits of address 0001	

· How to handle negative values

Negative values are expressed in 2's complement format.

The inverted bits of a positive value plus "1" means a negative value.

Example: If the 16-bit data is -1

1 (positive) = 01	000000000000000000000000000000000000000
↓	
1's complement (inverted)	111111111111111110
↓ 2's complement (1's complement + 1) = -1 = FF	1111111111111111111

(4) Check code (CRC)

CRC check codes are added to both command and response messages by using Modbus/RTU communication protocol.

The section from the station address to just before the check code in the message is included in the calculation.

For calculation, the binary data in the message is used without change. The check code is 16-bit data and can be calculated using the C programming language function "get_crc16()" shown in the following section. In a message, the first bytes of the code follow the last bytes. This order is the reverse of that of other 16-bit data.

Example: If the check code is 1234

Byte	Data (hex)	Description
1st	34	Last 8 bits of the data
2nd	12	First 8 bits of the data

```
<Sample of CRC check code calculation>
 [Argument 1] Character string length (No. of bytes)
 [Argument 2] Character string's head pointer
  [Function value] Calculation result
  UH get_crc16(INT len, UB *p)
 {
   UH dt_16;
   UH next;
   UH carry;
   INT i;
   dt 16 = 0xffff;
   while (len > 0) {
     next = (UH)*p;
     dt 16 ^= next;
     for (i = 0; i < 8; i++) {
       carry = (UH)(dt \ 16 \& 0x0001);
       dt_16 >>= 1;
       if (carry != 0) {
         dt 16 ^= 0xA001;
       }
     }
     p++;
     len--;
   return dt_16;
 }
```

(5) Start and end

In the Modbus/RTU communication protocol, a silent interval (non-communication time) equivalent to at least 3.5 characters is required for both the start and end of a command message and response message. However, the following specifications apply to the K1G controller.

Transmission speed	Silent interval
9,600 bps	8 ms
19,200 bps	4 ms
38,400 bps	2 ms
115,200 bps	1 ms

LIST OF FUNCTION CODES

The following function codes are available for the controller.

Code (he	x) Function name	Description
03	Continuous data read	Reads the specified No. of continuous data records from the specified address.
10	Continuous data write	Writes the specified No. of continuous data records from the specified address.

CONTINUOUS DATA READ (FUNCTION CODE: 03)

Reads the specified No. of continuous data records from the specified address. Up to 125 data records can be read with a single instruction message.

03

Command format

Station Function code		DATA		
		Address	No. of data records	CRC
(1)	(2)	(3) (4)		(5)
1 byte	1 byte	2 bytes 2 bytes		2 bytes

(1) Station address

(2) Function code:

(3) Starting address for reading data

(4) No. of read data records (addresses)

(5) Check code (CRC)

Response format (for a normal response)

Chatlan	Europei en en el e		D	ATA		CDC
Station	Function code	Byte	1st data record		Nth data record	CRC
(1)	(2)	(3)	(4)		(5)	(6)
1 byte	1 byte	1 byte	2 bytes		2 bytes	2 bytes

(1) Station address

(2) Function code: 03

(3) No. of read data bytes: double the sum of (4)+(5)

(4) 1st data record

(5) Nth data record

(6) Check code (CRC)

Exception responses (P. 5-18)

CONTINUOUS DATA WRITE FUNCTION (FUNCTION CODE: 10)

Writes the specified No. of continuous data records from the specified address. Up to 123 data records can be written with a single instruction message.

If settings are changed in Run mode, an amount of time equivalent to 128 samples (128 \times sampling time) will be spent in Ready mode to apply the changed settings, and then the mode will return to Run.

• Command format

			DATA					
Station Function code	۸ ما ما <u>س</u> م م	No. of data	Durte	1st data		Nth data	CRC	
		Address	records	rds Byte	record		record	
(1)	(2)	(3)	(4)	(5)	(6)]	(7)	(8)
1 byte	1 byte	2 bytes	2 bytes	1 byte	2 bytes		2 bytes	2 bytes

(1) Station address

(2) Function code:

(3) Starting address for writing data

(4) No. of write data records (No. of addresses)

(5) No. of write data bytes: double the sum of (6)+(7)

10

(6) 1st data record

(7) Nth data record

(8) Check code (CRC)

Response format (for a normal response)

Ctation	Function code		CDC		
Station	Function code	Address	No. of data records	CRC	
(1)	(2)	(3)	(4)	(5)	
1 byte	1 byte	2 byte	2 byte	2 byte	

(1) Station address

(2) Function code: 10

(3) Starting address for writing data

(4) No. of write data records

(5) Check code (CRC)



Exception responses (P. 5-18)

EXCEPTION RESPONSES

If the controller was not able to process the received function code successfully, it will return an exception response according to the Modbus communications protocol. An error involving any function code results in the exception response.

Format of the exception response

Station	Function code	Error code	CRC
(1)	(2)	(3)	(4)
1 byte	1 byte	1 byte	1 byte

(1) Station address

(2) Function code: Continuous read data = 03 (hex): 83 (hex)

Continuous write data = 10 (hex): 90 (hex)

Note: The command's function code + 80

- (3) Error code: See the list of error codes.
- (4) Check code (CRC)

List of error codes

Code (hex)	Name	Description
01	Illegal function	Unsupported function code
02	Illegal data address	Data address error (inaccessible area) Error in the number of data records (the No. is out of range, inaccessible area)
03	Illegal data	The written value is out of range. Error in the number of bytes of the function code. Error in the number of data records or bytes. Writing or reading is prohibited due to instrument conditions.
10	Application error 1	Reserved
11	Application error 2	Reserved
12	Application error 3	High-speed trend overrun error
13	Application error 4	Write mode error
14	Application error 5	Reserved
15	Application error 6	Reserved



SZ-D01 CONFIGURATION TOOL


This chapter describes the SZ-D01 configuration tool. Before use, please read "Handling Precautions for the SZ-D01 Configuration Tool for K1G Series High-Accuracy Position Sensors" (manual No. CP-UM-5785JE), which is included with the SZ-D01. Also, read "GP-4201TM/4301TM Installation Guide" and "Warning/Caution Information" (both included with the display unit) in order to use the equipment correctly.

6-1	System Configuration	6-2
6-2	Installation and Wiring	6-4
6-3	Basic Operation and Functions	6-7

6-1 System Configuration

SYSTEM CONFIGURATION

The SZ-D01 configuration tool consists of a display unit with the pre-installed dedicated software, stand, cables, etc.



FUNCTIONS

ltem		Description
Setting/Adjustment		Setup of various parameters and receiver adjustment.
Monitoring	Trend monitor	Collects data from 4 channels on a 1 s (minimum) cycle and displays data in a graph format.
	High- speed trend	Collects data from 1 channel 40000 times during the measurement cycle (500 μ s/1 ms) set for the K1G, and displays the data in a graph format.
Event Log		Reads out and displays various event log settings and data collected and saved to the controller by the event log func- tion.
Other		I/O test, Replacement procedure, Application specific set- ting.

STORING DATA IN A USB FLASH DRIVE

The settings and acquired monitoring data, etc., can be saved to a USB storage device (not included).

An operational check has been done with the following USB flash drives connected to the display unit.


Manufacturer	Product name	Capacity
Buffalo Inc.	RUF-C/U2	1 GB
	RUF-C256M/U2	256 MB
Green House Co., Ltd.	GH-UFD1GSLT	1 GB
Transcend Japan	JFV10	1 GB

Depending on the production date, some USB flash drives cannot be used due to a change in manufacturing specifications.

Because of this, do an operational check before use.

Data storage directories

Data stored in a USB flash drive will be saved as shown below.




Note: _ _ _ _ represents a number.

6-2 Installation and Wiring

For installation and wiring, see also user's manual GP-4201TM/4031TM, which is included with the display unit.

ATTACHING THE DISPLAY UNIT TO THE STAND

Attach the anti-rotation tee to the display module. Insert the display module connector and tee into the appropriate holes in the stand. Attach the nut to the display module connector and tighten it using the included socket wrench



! Handling Precautions


• Tightening torque: 1.2–2 N·m.

SZ-D01 CONFIGURATION TOOL

Insert the rear module connector into the display module connector until the modules are properly combined.

! Handling Precautions


• When combining the two modules, take care to orient them as shown in the figure below. If the orientation is wrong, the connectors may be damaged.



POWER WIRING

Connect the DC jack cable (sold separately) to the power plug


For the mounting screws, use a flat-tip screwdriver whose tip size is 0.6 x 3.5 mm.




! Handling Precautions

- Tightening torque: 0.5–0.6 N·m
- Do not solder the cable connections.

2 Connect the wired power plug to the display unit




3 Connect the DC jack cable to the AC adapter (both sold separately)




CONNECTING THE LOADER CABLE

Connect the serial connector on the loader cable to the display unit




2 Connect the loader cable jack to the loader port on the controller



6-3 Basic Operation and Functions

SCREEN TRANSITION DIAGRAM



SWITCHING THE MODE



Ready and Run modes can be checked and changed.

Before changing other settings, change the mode to Ready.


ICONS

lcon	Name	Description
	Тор	Redisplays the top menu screen.
BACK	Back	Moves the display one level above the current one.
	Next	Moves the display to the next settings screen.
	Camera	Captures a screen and stores it in a USB flash drive.
	Camera NG	Screen capture function is OFF. Connect a USB flash drive as needed.
٩	Loupe	Zooms into and out of the trend monitoring screen.
\diamondsuit	Change	Changes between screen display modes.
HELP	Help	Shows further notes.

MONITORING


Measurement data

The measurements on each channel, event status, etc., can be checked.



Trend monitor


Displays the measurements on as many as 4 channels in graph format.



* Unit: seconds. Range: 0 to 65535 (when 0 is specified, there is no sampling)

High-speed trend monitor

Obtains data from 1 channel 40000 times per measurement cycle and displays the data in graph format.



REPLACEMENT PROCEDURE

Pressing an icon like this one b displays the corresponding step of the procedure.

Replacement proc of the controller	cedure 🚮 📥
Save configuration	The configuration file is saved to external memory
Power supply OFF	Controller power supply is turned OFF
Replacement	Replace the controller
Power supply ON	Controller power supply is turned ON
Initial setting	Initial setting of the controller is perform
Read configuration	The configuration file is read from external memory
Mode Ready Run	
	\uparrow

Pressing an icon displays the corresponding step of the procedure.

SETTINGS/ADJUSTMENTS

Various parameters can be changed and light reception can be adjusted.

• Settings screen

DI/O setting[1]		1	To configure all channels at the same time, touch and change the value under ALL.
-3.500 -3.500 -3.500 -0.000 Event threshold upper limit PV1 PV2 PV3 PV4 ALL 3.500 3.500 3.500 0.000 0.000 0.000 0.000	(<u>1</u>) - (2)	2	To configure an individual channel, touch and change the relevant value.
PV1 PV2 PV3 PV4 ALL 0.010 0.010 0.010 0.000 Undo Enter Save	(3)	3	Saves changed settings to the controller.
Mode Ready Run > > > >	<u>.</u>	4	Finalizes a changed setting.
	5	5	Undoes the preceding change.

In Ready mode, the changed setting can be saved to the controller.

Receiver adjustment screen

Light receiving adjustment[2]		1	Changes between the graphs for each channel.
Ch1 / Ch2 / Ch3 / Ch4 Receiving	-[] -	2	Adjusts the received light.
adjustment Save	-2 - -3 _	3	Saves the adjustment data to the controller.
Mode Ready Run			

Waveform example: receiver adjustment is possible.






Waveform example: receiver adjustment is not possible.




I/O TEST




EVENT LOG

Event log settings and acquired data can be checked.


Settings screen



Log data



• Light receiving profile capture



PERFORMANCE SPECIFICATIONS FOR THE DISPLAY UNIT

Display device	TFT color LCD		
Display size	5.7 inches		
No. of display dots	320 × 240 (QVGA)		
Displayed colors	65356		
Backlight	White LED (cannot be changed)		
Brightness adjustment 16 levels (adjustable by the touch panel)			
External data storage	USB 2.0 connector: Type A (1) Supply voltage: 5 V DC ±5 % Max. communication distance: 3 m		
Supported languages	Japanese, English, Korean, Chinese (simplified & traditional), German		
Backup memory	128 Kbyte		
Rated voltage	24 V DC		
Power consumption	6.8 W max.		



SPECIFICATIONS

This chapter gives the specifications for the K1G series.

7-1	Sensor Heads	7-2
7-2	Controllers	7-5
7-3	Junction Cables	7-8
7-4	Ferrite core	7-9

7-1 Sensor Heads

SPECIFICATIONS

Model No		K1G-S07	K1G-S15
	ble controller	K1G-C04 G	
Sensing m			ru-scan
Sensing d		10–500 mm	10–1000 mm
	nent width	7 mm	15 mm
Light sour	rce	Red semiconductor lase	r (peak wavelength: 650 nm),
_		SIC	class 1
Standard	target object	Opaqu	e knife edge
Repeatabl	ility	±1 μ	m max.*1
Moving ad	ccuracy	±20 μm max. for a	movement of 0.5 mm*2
Indicators	Emitter	Laser emission i	ndicator (green LED)
	Receiver	Normal operation / k	beam alignment indicator
		(gre	een LED)
Operat-	Operating temperature	0	–50 °C
ing envi-	Storage temperature		(without freezing)
ronment	Operating ambient humidity	30–85 % RH (wi	thout condensation)
	Vibration resistance	9.	8 m/s ²
		(10 to 55 Hz for 2 h ea	ch in x, y, and z directions)
	Protective structure	IP40 (IE	C standard)
Material	Controller		PPS
	Light-emitting and receiving		Glass
	surfaces		
	Cable		PVC


*1. The accuracy specifications are under the conditions shown below, at an ambient temperature of 23 \pm 2 °C.

Model No.	SD	WD	Workpiece position	No. of moving averages
K1G-S07	20 mm	10 mm	Center of measurement width	<i>C</i> A
K1G-S15	100 mm	50 mm	1.0 mm from center of measurement width	64

*2. The accuracy specifications are under the conditions shown below, at an ambient temperature of 23 ± 2 °C.

Model No.	SD	WD	Workpiece position
K1G-S07	20 mm	10 mm	Center of measurement width
K1G-S15	100 mm	50 mm	1.0 mm from center of measurement width


SD: sensing distance (emitter to receiver) WD: working distance (target object to receiver)



EXTERNAL DIMENSIONS


• K1G-S07 (sensor heads)

Unit: mm



• K1G-S15 (sensor heads)

Unit: mm



*¹ Total light emission area: $23(H) \times 6(W)$ *² Center of the measurement width

SPECIFICATIONS

Model No.		K1G-C04G	K1G-C04MG	K1G-C04EG	
Compatible sensor		K1G-S			
Max. pairs of	sensor heads		4		
Junction cal	ole	K1G-LS,	K1G-R S		
Min. display	unit	0.1	μm		
Display range	With KG-S07	±3.5	mm		
	With KG-S15	± 7.5	mm		
Measureme (output upd		500 μs / 1 ms	(switchable)*1		
Analog outp	but	4 1–5 V (voltage output) or 4–20 mA (current output) Load resistance: 10 k Ω min. (with voltage output) 250 Ω +1 % max. (with current output)	-		
Digital output *2		8 common outputs (shared with power terminals) NPN or PNP output (selectable) Output current: 1–10 mA (each output) ON-state voltage drop: 2 V max. OFF-state leakage current: 0.3 mA max.	-		
Digital input		4 common outputs (shared with power terminals) Non-voltage contacts and open collector NPN or PNP output (selectable) Input current: Approx. 4 mA max. Min. input time: 12 ms (at a 500 µs measurement cycle) 24 ms (at a 1 ms measurement cycle)			
Communicati	ions function	RS-485 (Modbus RTU)	MECHATROLINK-III	EtherCAT	
Supply pow	er	12–24 V [DC ±10 %		
Current con	sumption	1 A max. at 24 V,	2 A max. at 12 V		
Inrush curre	nt	20 A (0.2 s) max.			
Operating te	emperature	0–50 °C (0–35 °C when 3 or m	nore units are gang-m	ounted)	
Storage tem	perature	-20 to +70 °C (w	vithout freezing)		
Operating am	bient humidity	30–85 % RH (with	out condensation)		
Vibration res		2 m/s ² (10 to 60 Hz for 2 h e	ach in x, y, and z dire	ctions)	
Shock resist	ance	10 m/s ² , 3 times in x	x, y, and z directions		
Protection c	ircuit	Power miswir	ing protection		
Pollution de	gree	Pollution degree 2			

*1. The list of selectable measurement cycles varies depending on the cable length. See the following table to select the cable length corresponding to the desired measurement cycle.


Model No.	Measurement cycle		
wodel no.	500 µs	1 ms	
K1G-LS	20 m max.	25 m max.	
K1G-RS	5 m max.	10 m max.	

Note: The listed lengths are for junction cables. 🏈 P. 7-8


*2. Not open collector output.


EXTERNAL DIMENSIONS

K1G-C04G (controller)




• K1G-C04MG (controller)





Sensor head cable



SPECIFICATIONS

Standard model

Model No.	K1G-L01S	K1G-L03S	K1G-L05S	K1G-L10S	K1G-L25S
Cable length (L)	1 m	3 m	5 m	10 m	25 m


Bend-tolerant model

Model No.	K1G-R01S	K1G-R03S
Cable length (L)	1 m	3 m

EXTERNAL DIMENSIONS


Standard model

Unit: mm



Bend-tolerant model





SPECIFICATIONS


Model No.			SZ-E01	SZ-E02
Material	Ferrite core	Soft ferrite		
	Case	PA66	Color:	Light gray
			Flammability sta	ndard: UL94 V-0
Wire bundle diameter		8	.5 to 9.5 mm	20 mm max.

SZ-E01 is equivalent to GRFC-9 made by Kitagawa Industries Co., Ltd. SZ-E02 is equivalent to RFC-20 made by Kitagawa Industries Co., Ltd.

EXTERNAL DIMENSIONS


• SZ-E01


unit: mm



• SZ-E02

unit: mm











TROUBLE SHOOTING

This chapter tells how to determine the causes of problems that may arise while using K1G series sensors, and what corrective actions to take.

Troubleshooting

FREQUENTLY ASKED QUESTIONS





Problems with the sensor heads

No.	Problem	What to check	Corrective action	Reference page
1	Emitter indicator does not light up.	Wiring for the emitter	Correct the wiring.	C P. 2-7
2	Receiver indicator	Wiring for the receiver	Correct the wiring.	🕩 Р. 2-5
	does not light up.	Optical axis position (in Ready mode)	Adjust the optical axis position correctly.	C P. 3-8
		Power-saving mode	Turn off power-saving mode.	ГЭ Р. 4-98

Problems with the controller

No.	Problem	What to check	Corrective action	Reference page
-	The display is blank.	Power wiring for the controller	Correct the wiring.	🖒 P. 2-7
1	The operation indi- cator is not lit.	-	Contact the azbil Group.	-
2	The mode cannot be switched to Run.	Initial setup completion	Complete the initial setup.	С Р. 3-3
3	No values are dis- played.	Power-saving mode	Turn off power-saving mode.	🕩 P. 4-98
	The displayed value does not change.	Calculation OFF input is enabled.	Disable calculation OFF input.	C P. 4-36
		Hold function status (is "Hold" status indicator lit?)	Disable the hold func- tion.	CP P. 4-36 P. 4-79

Troubleshooting

No.	Problem	What to check	Corrective action	Reference page
4	A sensor connec- tion indicator is	Initial setup completion	Adjust the receiver of the blinking channel.	С Р. 3-8
	blinking.	Were sensor heads re- placed?	Reset, then adjust posi- tion of optical axis.	€ P.4-106
	A sensor connec- tion indicator is not lit.	Wiring for the sensor heads	Correct the wiring.	ГЭ Р. 2-5
(5)	DO signal is not	Wiring for the DO signal	Correct the wiring.	🗭 P. 2-9
	output.	Ready mode.	Switch the mode to Run.	🗭 P. 4-4
	There is no re-	Wiring for the DI signal	Correct the wiring.	🗭 P. 2-10
	sponse to DI signal input.	Calculation OFF input is enabled.	Disable calculation OFF input.	🗭 P. 4-36
6	Keys do not oper- ate.	Key lock	Disable the key lock.	€ P.4-105
	Cannot set param- eters.	Run mode	Switch the mode to Ready.	🕼 P. 4-4
7	AO signal is not output.	Wiring for the AO signal	Correct the wiring.	🕼 P. 2-11
	The AO signal does not change.	Ready mode.	Switch the mode to Run.	🕼 P. 4-4
		Calculation OFF input is enabled.	Disable calculation OFF input.	🕼 P. 4-36
		Hold function status (is "Hold" status indicator lit?)	Disable the hold func- tion.	€ P. 4-36 P. 4-79

Troubleshooting

Measurement problems				
No.	Problem	What to check	Corrective action	Reference page
1	Measured values fluctuate.	Smudge on the sensor heads	Wipe with a soft dust- free cloth.	🗭 P. vi
2		Vibration of the work- piece	Reexamine the mea- surement position, etc.	-
3		Sensor head optical axis alignment	Check the optical axes and adjust the receiver.	СЭ́Р. 3-8
4		Workpiece settings	Adjust the settings.	🗭 P. 4-11
5		Ambient light interfer- ence	Reexamine the mea- surement position, etc.	-
6	The measured value is not correct.	Smudge on the sensor heads	Wipe with a soft dust- free cloth.	🕼 P. vi
7		Workpiece settings	Adjust the settings.	🕼 P. 4-11
8		Zero adjustment	Check the zero adjust- ment setting.	🕼 P. 4-29
9	The DO for mea- surement status is not correct.	DO settings	Check DO operation type, thresholds, etc.	🗭 P. 4-42
10		Selected channel	Check the setting for the selected channel.	🗭 P. 4-42

Measurement problems

• Communication problems

No.	Problem	What to check	Corrective action	Reference page
1	RS-485 communi- cation is not work-	Wiring for communica- tions	Correct the wiring.	С Р. 2-12
2	ing normally.	Communication set- tings	Check communica- tion-related settings.	СЭ́Р. 5-2
3	MECHATROLINK-III communication is not working nor-	Cable connection status (check link indicators LK1 and LK2).	Insert the connector until it clicks.	ГЭ Р. 2-14
4	mally.	A. Station address and No. Correct the relevant of transmission bytes settings including those of the master station and other devices.		€ P.4-108 € P.4-111
5	EtherCAT com- munication is not working properly.	not indicator to check the until it clicks.		€ P. 2-15
6		Check the RUN and ERROR indicators.	Determine the state of EtherCAT com- munication from the indicators and take appropriate counter- measures.	€ 3 P. 1-14
7		Check the settings of the ECAT ID setting switches.	Check the master de- vice for the ID of other slave devices and specify a unique ID.	€ P. 3-11
8		Check if there is a source of heavy electrical noise in the environment.	Reexamine the instru- mentation method.	₽ . 2-16

Display 1	Display 2	Error	Corrective action
rrar		System error	Replace the controller.
		System error	
	Сар Чар Чар	System error	
		Data corruption in EE- PROM	Contact the azbil Group.
		Channel 1 sensor head disconnection	Check the relevant cables, etc., and replace the sensor heads if necessary.
		Channel 2 sensor head disconnection	If multiple sensor head sets are used, unless all of them are dis- connected, "Error" will not be
	5 4	Channel 3 sensor head disconnection	displayed.
	128	Channel 4 sensor head disconnection	-
	256	MECHATROLINK-III error	Check the MECHATROLINK-III communication configuration, referring to user's manual No. CP-SP-1386E. Also, check the relevant settings for the master station.
	5 12	EtherCAT communica- tion error	Replace the controller.

Note: If multiple errors occur at the same time, the sum of the error codes will be displayed.



Parameters, 7-segment LED characters and numbers, etc.

9-1	Parameters
9-2	Configuration Flowcharts9-7
9-3	Processing Flowchart
9-4	Alphanumeric Characters
9-5	If the Product Is Used Outside Japan9-14
9-6	Communication Parameters9-15
9-7	Important Notes for Restarting the Laser Beam 9-31

9-1 Parameters

Dis- play	Description	Parameter	Default setting	Reference page
R0 I	Measurement cycle	500u: 500 μs Ι000u: 1 ms	5 <i>00</i>	P. 4-15
802	Display resolution	99.9:1 digit after the decimal point99.99:2 digits after the decimal point99.99:3 digits after the decimal point99.99:2 digits after the decimal point	9.999	P. 4-8
R03	Key lock	 <i>aFF</i>:Disabled <i>an</i>: Enabled 	oFF	C P.4-102
R04	Controller power- saving mode	 <i>aFF</i>:Disabled <i>an</i>: Enabled 	oFF	C P. 4-98
<i>R05</i>	Sensor head power- saving mode	oFF:Disabled	oFF	🕼 Р. 4-98
<i>R06</i>	Station address	Image:	۵	р. 5-4 €
гол	Transmission speed	9.5: 9.6 kbps 19.2: 19.2 kbps 38.4: 38.4 kbps 115.2: 115.2 kbps	9.6	P. 5-7
R08	Communication format	DenE:No parity (2 stop bits)EUEn:Even parity (1 stop bit)odd:Odd parity (1 stop bit)	nonE	P. 5-10
R09	MECHATROLINK-III address	Зь to ЕFь Note: "3" is displayed on the K1G- C04G, but it cannot be changed.	34	€ P.4-108
R 10	No. of transmission bytes for MECHA- TROLINK-III Note: This param- eter will not be displayed on the K1G- C04G.	48: 48 byte 32: 32 byte	48	CP-SP- 1386E
60 I	Sensor head type (display only, un- changeable)	: Not connected ::: -: -: Not connected :: -: -: -: Not connected :: -: -: -: Not connected :: -: -: -: Not connected :: -: -: -: -: -: -: -: -: -: -: -: -: -	_	-

Dis- play	Description		Р	arameter	Default setting	Reference page	
602	Measurement mode		easure- ent mode	Target ob- ject type	Measurement orientation	1	P. 4-11
			ge mea- rement	Opaque object Trans-	Top Bottom Top		
		ч		parent object	Bottom		
		m	idth easure- ent	Opaque	-		
		su	ap mea- irement	object	-		
		8 wi	lge idth easure- ent	Trans- parent	Top Bottom		
		З _{Меа}	asurement second edge	object	Top Bottom		
603	No. of moving averages	1-50	0		<u>54</u>	P . 4-18	
684	Smudge detection threshold	1-10	0 (%) (0	: disabled)	0	P. 4-90	
60S	Edge detection threshold	5-95	(%)		25	P.4-21	
606	Zero adjustment value				1–3.500 (mm) 1–7.500 (mm)	0.000	P. 4-29
607	Working distance (WD)	All mo	dels:	0-9	(disabled)	0	P. 4-76
	* This parameter is	With K	1G-S07 s	ensor: 10-	-5 <i>00</i> (mm)		
	displayed but the function is not yet implemented.	With K	(1G-S15 s	ensor: 10-			
E 0 I	Inter-channel calcu-		: Disabl			nonE	🗭 P. 4-62
	lation				operations		
		F - KA		culation (c y can be s			
		F-EH	l E : Meas sion	surement r calculation only can be			
203	Hold setting		: disab		nonE	P. 4-79	
				ut (DI) max. val			
			•	ıt (DI) min. valı			
			:EPS fi 2:EPS fi				
			<i>3</i> :EPS fi				
		EP5-	५:EPS fi	lter 4			
		EP5-	5:EPS fi				

9-1 Parameters

Dis- play	Description	Parameter	Default setting	Reference page
C O 3	No. of EPS filter delays	1-256	1	🗭 P. 4-83
C 0 4	EPS filter size	<i>0. 100–50.000</i> (mm)	0. 100	C P. 4-83
<i>CO</i> 5	EPS filter direction	ይወይት:Concave and convex	both	C P. 4-83
		r ،5E:Convex]	
		dr oP:Concave		
C 0 6	EPS filter output	oFF: Disabled	00	🗭 P. 4-83
	hold	en: Enabled		
רםם	Low threshold	With K1G-S07: - 99.999 to + 99.999 (mm)	- 3.500	🗭 P. 4-42
		With K1G-S15: - 99.999 to + 99.999 (mm)	- 7.500	
C 0 8	High threshold	With K1G-S07: - \$9.999 to +\$9.999 (mm)	3.500	🗭 P. 4-42
		With K1G-S15: - 99999 to +99999(mm)	500 ר.	
609	Hysteresis	0.0 10- 1.000 (mm)	0.0 10	C P. 4-42
C 10	Analog output re-	<i>aFF</i> : disabled (positive polarity)	oFF	🗭 P. 4-33
	verse polarity	en: enabled (negative polarity)		
E 1 1	Analog output range	With K1G-S07: - 99.999 to + 99.999 (mm)	- 3.500	🗭 P. 4-25
	low limit	With K1G-S15: - 99.999 to + 99.999 (mm)	- 7.500	
E 12	Analog output range	With K1G-S07: - \$3.555 to + \$3.555 (mm)	3.500	🗭 P. 4-25
	high limit	With K1G-S15: - 99.999 to + 99.999 (mm)	1.500	
40 1	Calculation parameter K1	- 1000 to + 1000	1	CP P. 4-62
402	Calculation parameter K2	- 1000 to + 1000	1	P. 4-62
403	Calculation parameter K3	- 1000 to + 1000	1	P. 4-62
804 8	Calculation parameter K4	- 1000 to + 1000	1	P. 4-62
d05	Calculation parameter C1	-9.999 to +9.999	0.000	P. 4-62
405	Calculation parameter C2	1- 10000	Ч	🗭 P. 4-62
E0 I	Event source	د مة: All channels (OR output)	Selected	🗭 P. 4-42
		Eh I: Channel 1 (for PV1)	channel	
		E ト 2: Channel 2 (for PV2) E ト 3: Channel 3 (for PV3)	-	
		Ehy: Channel 4 (for PV4)	-	
503	Event type	PR55: Pass	PRSS	C P. 4-42
		out: Out	1	₩ 1. 1 12
		hi: High	1	
		Lo: Low	1	
		EPS: EPS event	1	
		hald: Holding	1	
		ני <u>ה</u> אב: Smudge	1	
		ይ	1	
		นียากนี้: Normal operation		

Dis- play	Description	Parameter	Default setting	Reference page
E 0 3	Delay setting	nenE: Disabled	nonE	C P. 4-42
		စဂ - d: ON delay		
		<i>ьF</i> - <i>d</i> : OFF delay		
E04	Delay time	/[]: 10 (ms)	40	C P. 4-42
		20:20 (ms)		
		3 🖸: 30 (ms)		
		ዛ : 40 (ms)		
		50:50 (ms)		
		<i>Б ជ</i> : 60 (ms)		
		ገ ር: 70 (ms)		
<i>E05</i>	Event source	្រី ៨ភូ: All channels (OR output)	Selected	C P. 4-42
		Eh I: Channel 1 (for PV1)	channel	
		Eh己: Channel 2 (for PV2)		
		<i>E</i> ト <i>3</i> : Channel 3 (for PV3)		
		じちょ: Channel 4 (for PV4)		
E 0 6	Event type	PR55: Pass	002	C P. 4-42
		out: Out		1.1 12
		க _் : High		
		Lo: Low		
		EPS: EPS event		
		held: Holding		
		L ، ፲ አ ይ: Smudge	_	
		<i>בר יב</i> : Output update	_	
		រកប៊ី: Normal operation		
207	Delay setting	nonE: Disabled	nonE	🗭 P. 4-42
		on-d: ON delay		
		oF - d: OFF delay		
E08	Delay time	10: 10 (ms)	40	🗭 P. 4-42
		20:20 (ms)	_	
		30: 30 (ms)	_	
		<i>ዛቤ</i> : 40 (ms)	_	
		5 <i>0</i> : 50 (ms)		
		δΩ : 60 (ms)	_	
		7፲ : 70 (ms)		


9-1 Parameters


Dis- play	Description		Parameter	Default setting	Reference page
E09	DI function selection	0-8dJ:	Zero adjustment for the specified channel	0-84J	C P. 4-36
		EP5:	EPS hold cancellation input for the specified channel		
		PU-h:	PV hold input for the specified channel		
		RLL D-RdJ:	Zero adjustment for all channels		
		RLL EPS:	EPS hold cancellation input for all channels		
		RLL PU-h:	PV hold input for all channels		
		RLL F-EPS	: Forced EPS hold can- cellation input for all channels		
		RLL Ld-on	: Laser start input for all channels		
		RLL do-oF	: Calculation OFF input for all channels		
		RLLLoG:	Event log start input for all channels		


9-2 Configuration Flowcharts


OVERALL FLOWCHART


For details, see the page noted under the item.












9-3 Processing Flowchart



9 APPENDIX

9-4 Alphanumeric Characters

The 7-segment LED display of the controller shows numbers as follows.

0	1	2	3	4	5	6	7	8	9
			רין	Ч	5	5		B	[]]

Alphabetic characters appear as follows on the LED display.

Α	В	С	D	E	F	G	Н		J	K	L	М
\overline{R}	6	Ľ	<i>d</i> ′	E	F	5	\mathbf{h}	1	1	<i>¦_'</i>	1	Ē
Ν	0	Р	Q	R	S	Т	U	V	W	Х	Y	Ζ
	0	\mathcal{D}	Q	-	5	-		11	11	Н	Ц	-

9-5 If the Product Is Used Outside Japan

CE MARK AND KOREA CERTIFICATION MARK

This product complies with the RoHS Directive (EN 50581: 2012). This product complies with the EMC Directive (EN 61326-1: 2013) for the instrumentation described in Chapter 2, INSTALLATION AND WIRING. This product complies with KC marking (Korean Radio Waves Act) for the instrumentation described in Chapter 2, INSTALLATION AND WIRING.

IF THE PRODUCT IS USED IN THE UNITED STATES

If equipment incorporating this device is exported to the United States, it will be subject to U.S. FDA laser safety requirements.

This product has been registered with the FDA (CDRH).

It includes a label indicating compliance with FDA standards. In the case of export to the United States, attach the label to the product.

DETAILS ON COMMUNICATIONS DATA

Definitions of items in the tables below are as follows.

Address :	Controller memory address (hexadecimal)
Size :	Parameter size (number of addresses) 1 : (16-bit data) 2 : (32-bit data)
Access rights :	Parameter access rights R : read W : write
Change enabled mode :	The mode in which parameters can be written RDY : Ready mode RUN : Run mode UT : UserTest mode

FOR MONITORING

Address (hex)	Size	Access rights	Change en- abled mode	Description	Notes
1000	2	R	-	PV1	Integer, ± 999999 (in 0.1 µm increments)
1002	2	R	-	PV2	Integer, ± 9999999 (in 0.1 µm increments)
1004	2	R	-	PV3	Integer, ± 9999999 (in 0.1 µm increments)
1006	2	R	-	PV4	Integer, ± 9999999 (in 0.1 µm increments)
1008	1	R	-	Event occurrence (channels 1–4, OR)	Table 1-A
1009	1	R	-	Ch1 event occurrence	Table 1-A
100A	1	R	-	Ch2 event occurrence	Table 1-A
100B	1	R	-	Ch3 event occurrence	Table 1-A
100C	1	R	-	Ch4 event occurrence	Table 1-A
100D	1	R	-	DI status	Table 1-B
100E	1	R	-	DO status	Table 1-C
100F	1	R	-	Controller status	Table 1-D
1010	1	R	-	Error status bit	Table 1-E
1011	1	R	-	Sensor head pair 1 status	Table 1-F
1012	1	R	-	Sensor head pair 2 status	Table 1-F
1013	1	R	-	Sensor head pair 3 status	Table 1-F
1014	1	R	-	Sensor head pair 4 status	Table 1-F

9-6 Communication Parameters

Table 1-A							
Assignment	Event occurrence status						
Bit 0	Pass event occurrence						
Bit 1	Out event occurrence						
Bit 2	High event occurrence						
Bit 3	Low event occurrence						
Bit 4	EPS event occurrence						
Bit 5	Hold event occurrence						
Bit 6	Smudge detection event occurrence						
Bit 7	Output update event occurrence						
Bit 8	Normal operation event occurrence						
Bits 9–15	No assignment (always 0)						

Та	b	le	1	-B

Assignment	Event occurrence
Bit 0	DI1: ON =1, OFF = 0
Bit 1	DI2: ON =1, OFF = 0
Bit 2	DI3: ON =1, OFF = 0
Bit 3	DI4: ON =1, OFF = 0
Bits 4–15	No assignment (always 0)
	·

Note: 1 = event occurrence, 0 = no occurrence

Table 1-C

Assignment	Event occurrence					
Bit 0	DO1: ON =1, OFF = 0					
Bit 1	DO2: ON =1, OFF = 0					
Bit 2	DO3: ON =1, OFF = 0					
Bit 3	DO4: ON =1, OFF = 0					
Bit 4	DO5: ON =1, OFF = 0					
Bit 5	DO6: ON =1, OFF = 0					
Bit 6	DO7: ON =1, OFF = 0					
Bit 7	DO8: ON =1, OFF = 0					
Bits 8-15	No assignment (always 0)					

Table 1-D Assignment Controller status Bit 0 No error Bit 1 Partial sensor head disconnection Device failure Bit 2

Table 1-E

Assignment Error status bit			
Bit 0	CPU in infinite loop		
Bit 1	FPGA malfunction		
Bit 2	ROM error		
Bit 3	EEPROM error		
Bit 4	Ch1 sensor head disconnection		
Bit 5	Ch2 sensor head disconnection		
Bit 6	Ch3 sensor head disconnection		
Bit 7	Ch4 sensor head disconnection		
Bit 8	Bit 8 MECHATROLINK-III communication error		
Bits 9–15	No assignment (always 0)		

Table 1-F

Value	Sensor head status				
0	Not connected				
1	Not adjusted				
2	In use				
3	Wrong connection				
4	Disconnected				
5	Prohibited				

Note: 1 = event occurrence, 0 = no occurrence

FOR SETTINGS

Share	Shared settings								
Address (hex)	Size	Access rights	Change enabled mode	Description	Notes				
2000	1	R/W	RUN, RDY	Measurement cycle	1: 500 μs 2: 1000 μs				
2001	1	R/W	RUN, RDY	Display resolution	No. of digits after the decimal point 0: 3 1: 2 2: 1 3: 4				
2002	1	R/W	RUN, RDY	Key lock	0: disabled 1: enabled				
2003	1	R/W	RUN, RDY	Controller power- saving mode	0: disabled 2: enabled				
2004	1	R/W	RUN, RDY	Sensor head power- saving mode	0: disabled 3: enabled				
2005	1	R/W	RUN, RDY	Station address	0–127 (0: RS-485 disabled)				
2006	1	R/W	RUN, RDY	Transmission speed	0: 9.6 kbps 1: 19.2 kbps 2: 38.4 kbps 3: 115.2 kbps				
2007	1	R/W	RUN, RDY	Communications format (parity)	0: None 1: Even 2: Odd				
2008	1	R/W*1	RUN, RDY	MECHATROLINK-III address	03-EF(HEX)				
20A1	1	R/W*2	RUN, RDY	No. of transmission bytes for MECHATROLINK-III	2: 32 bytes 3: 48 bytes				

- -. •

*1. "R" (READ) only in the case of K1G-C04G. *2. No access in the case of K1G-C04G.

• Individual channel settings

Ch1 address (hex)	Ch2 address (hex)	Ch3 address (hex)	Ch4 address (hex)	Size	Access rights	Change en- abled mode	Description	Notes
2009	2010	2017	201E	1	R	-	Sensor head type	0: Not connected 1: K1G-S07 2: K1G-S15
200A	2011	2018	201F	1	R/W	RUN, RDY	Workpiece	Table 2-A
200B	2012	2019	2020	1	R/W	RUN, RDY	No. of moving averages	1–500
200C	2013	201A	2021	1	R/W	RUN, RDY	Smudge detec- tion threshold	0–100 %
200D	2014	201B	2022	1	R/W	RUN, RDY	Edge detection threshold	5–95 %
200E	2015	201C	2023	1	R/W	RUN, RDY	Zero adjust- ment value	Integer, -3500 to +3500 μm Integer, -7500 to +7500 μm
200F	2016	201D	2024	1	R/W	RUN, RDY	Working dis- tance (WD)	S07: 0–500 S15: 0–1500, 0–9: Invalid

• Individual PV settings

PV1 address (hex)	PV2 address (hex)	PV3 address (hex)	PV4 address (hex)	Size	Access rights	Change en- abled mode	Description	Notes
2025	2035	2045	2055	1	R/W	RUN, RDY	Inter-channel calculation	0: No calculation 1: Four arithmetic operations 2: θ calculation* 3: Measurement range expansion calculation*
2026	2036	2046	2056	1	R/W	RUN, RDY	Hold setting	Table 2-B
2020	2037	2040	2057	1	R/W	RUN, RDY	No. of EPS filter delays	1–256
2028	2038	2048	2058	1	R/W	RUN, RDY	EPS filter size	Integer, 100 to 50000 μm
2029	2039	2049	2059	1	R/W	RUN, RDY	EPS filter direc- tion	0: Concave and convex 1: Convex 2: Concave
202A	203A	204A	205A	1	R/W	RUN, RDY	EPS filter output hold	0: Disabled 1: Enabled
202B	203B	204B	205B	2	R/W	RUN, RDY	Low threshold	Integer, -99999 to +99999 μm
202D	203D	204D	205D	2	R/W	RUN, RDY	High threshold	Integer, -99999 to +99999 μm
202F	203F	204F	205F	1	R/W	RUN, RDY	Hysteresis	Integer, 10 to 1000 μm
2030	2040	2050	2060	1	R/W	RUN, RDY	Analog output reverse polarity	0: Disabled 1: Enabled
2031	2041	2051	2061	2	R/W	RUN, RDY	Analog output range low limit	Integer, -99999 to +99999 μm
2033	2043	2053	2063	2	R/W	RUN, RDY	Analog output range high limit	Integer, -999999 to +99999 μm
2065	206B	2071	2077	1	R/W	RUN, RDY	Calculation parameter K1	-1000 to +1000
2066	206C	2072	2078	1	R/W	RUN, RDY	Calculation parameter K2	-1000 to +1000
2067	206D	2073	2079	1	R/W	RUN, RDY	Calculation parameter K3	-1000 to +1000
2068	206E	2074	207A	1	R/W	RUN, RDY	Calculation parameter K4	-1000 to +1000
2069	206F	2075	207B	1	R/W	RUN, RDY	Calculation parameter C1	Integer, -99999 to +99999 μm
206A	2070	2076	207C	1	R/W	RUN, RDY	Calculation parameter C2	1 to 10000

• DI and DO settings

		J	[1
Address (hex)	Size	Access rights	Change en- abled mode	Description	Notes
207D	1	R/W	RUN, RDY	DO1 Event source	0: Any 1: Ch1 2: Ch2 3: Ch3 4: Ch4
207E	1	R/W	RUN, RDY	DO1 event type	Table 2-C
207F	1	R/W	RUN, RDY	DO1 delay setting	0: No delay 1: ON delay 2: OFF delay
2080	1	R/W	RUN, RDY	DO1 delay time	Table 2-D
2081	1	R/W	RUN, RDY	DO2 event source	0: Any 1: Ch1 2: Ch2 3: Ch3 4: Ch4
2082	1	R/W	RUN, RDY	DO2 event type	Table 2-C
2083	1	R/W	RUN, RDY	DO2 delay setting	0: No delay 1: ON delay 2: OFF delay
2084	1	R/W	RUN, RDY	DO2 delay time	Table 2-D
2085	1	R/W	RUN, RDY	DI1 function selection	
2086	1	R/W	RUN, RDY	DO3 event source	0: Any 1: Ch1 2: Ch2 3: Ch3 4: Ch4
2087	1	R/W	RUN, RDY	DO3 event type	Table 2-C
2088	1	R/W	RUN, RDY	DO3 delay setting	0: No delay 1: ON delay 2: OFF delay
2089	1	R/W	RUN, RDY	DO3 delay time	Table 2-D
208A	1	R/W	RUN, RDY	DO4 event source	0: Any 1: Ch1 2: Ch2 3: Ch3 4: Ch4
208B	1	R/W	RUN, RDY	DO4 event type	Table 2-C
208C	1	R/W	RUN, RDY	DO4 delay setting	0: No delay 1: ON delay 2: OFF delay
208D	1	R/W	RUN, RDY	DO4 delay time	Table 2-D
208E	1	R/W	RUN, RDY	DI2 function selection	Table 2-E

Address	Size	Access	Change en-	Description	Notes
(hex)	JIZE	rights	abled mode	Description	Notes
208F	1	R/W	RUN, RDY	DO5 event source	0: Any 1: Ch1 2: Ch2 3: Ch3 4: Ch4
2090	1	R/W	RUN, RDY	DO5 event type	Table 2-C
2091	1	R/W	RUN, RDY	DO5 delay setting	0: No delay 1: ON delay 2: OFF delay
2092	1	R/W	RUN, RDY	DO5 delay time	Table 2-D
2093	1	R/W	RUN, RDY	DO6 event source	0: Any 1: Ch1 2: Ch2 3: Ch3 4: Ch4
2094	1	R/W	RUN, RDY	DO6 event type	Table 2-C
2095	1	R/W	RUN, RDY	DO6 delay setting	0: No delay 1: ON delay 2: OFF delay
2096	1	R/W	RUN, RDY	DO6 delay time	Table 2-D
2097	1	R/W	RUN, RDY	DI3 function selection	
2098	1	R/W	RUN, RDY	DO7 event source	0: Any 1: Ch1 2: Ch2 3: Ch3 4: Ch4
2099	1	R/W	RUN, RDY	DO7 event type	Table 2-C
209A	1	R/W	RUN, RDY	DO7 delay setting	0: No delay 1: ON delay 2: OFF delay
209B	1	R/W	RUN, RDY	DO7 delay time	Table 2-D
209C	1	R/W	RUN, RDY	DO8 event source	0: Any 1: Ch1 2: Ch2 3: Ch3 4: Ch4
209D	1	R/W	RUN, RDY	DO8 event type	Table 2-C
209E	1	R/W	RUN, RDY	DO8 delay setting	0: No delay 1: ON delay 2: OFF delay
209F	1	R/W	RUN, RDY	DO8 delay time	Table 2-D
20A0	1	R/W	RUN, RDY	DI4 function selection	Table 2-E

ValueWorkpiece1Opaque object edge measurement (top)2Opaque object edge measurement (bottom)3Transparent object edge measurement (top)4Transparent object edge measurement (bottom)5Opaque object width measurement6Opaque object gap measurement (top)7Transparent object edge measurement7Transparent object edge measurement8Transparent object edge width measurement (bottom)9Transparent object edge width measurement (bottom)9Transparent object 2nd edge position measurement (bottom)10Transparent object 2nd edge position measurement (bottom)	Talore	
2 Opaque object edge measurement (bottom) 3 Transparent object edge measurement (top) 4 Transparent object edge measurement (bottom) 5 Opaque object width measurement 6 Opaque object gap measurement 7 Transparent object edge width measurement (top) 8 Transparent object edge width measurement (bottom) 9 Transparent object 2nd edge position measurement (top)	Value	Workpiece
3 Transparent object edge measurement (top) 4 Transparent object edge measurement (bottom) 5 Opaque object width measurement 6 Opaque object gap measurement 7 Transparent object edge width measurement (top) 8 Transparent object edge width measurement (bottom) 9 Transparent object 2nd edge position measurement (top)	1	Opaque object edge measurement (top)
4 Transparent object edge measurement (bottom) 5 Opaque object width measurement 6 Opaque object gap measurement 7 Transparent object edge width measurement (top) 8 Transparent object edge width measurement (bottom) 9 Transparent object 2nd edge position measurement (top)	2	Opaque object edge measurement (bottom)
5 Opaque object width measurement 6 Opaque object gap measurement 7 Transparent object edge width measurement (top) 8 Transparent object edge width measurement (bottom) 9 Transparent object 2nd edge position measurement (top)	3	Transparent object edge measurement (top)
6 Opaque object gap measurement 7 Transparent object edge width measurement (top) 8 Transparent object edge width measurement (bottom) 9 Transparent object 2nd edge position measurement (top)	4	Transparent object edge measurement (bottom)
7 Transparent object edge width measurement (top) 8 Transparent object edge width measurement (bottom) 9 Transparent object 2nd edge position measurement (top)	5	Opaque object width measurement
8 Transparent object edge width measurement (bottom) 9 Transparent object 2nd edge position measurement (top)	6	Opaque object gap measurement
9 Transparent object 2nd edge position measurement (top)	7	Transparent object edge width measurement (top)
2nd edge position measurement (top)	8	Transparent object edge width measurement (bottom)
10 Transparent object 2nd edge position measurement (bottom)	9	
	10	Transparent object 2nd edge position measurement (bottom)

Ta	Table 2-B					
Va	alue	Hold setting				
	0	No hold				
	1	External input max. value hold				
	2	External input min. value hold				
	3	EPS filter 1				
	4	EPS filter 2				
	5	EPS filter 3				
	6	EPS filter 4				
	7	EPS filter 5				

Value	Event type
0	Pass
1	Out
2	High
3	Low
4	EPS event
5	Hold
6	Smudge detection
7	Output update
8	Normal operation

Table 2	Table 2-D						
Value	Delay time						
0	10 ms						
1	20 ms						
2	30 ms						
3	40 ms						
4	50 ms						
5	60 ms						
6	70 ms						

Table 2-E

Table 2-C

Value	DI signal function selection
0	Zero adjustment input
1	Input to cancel EPS filter output hold
2	Input for PV hold
3	Zero adjustment input for all channels
4	Input to cancel EPS filter output hold for all PVs
5	PV hold input for all PVs
6	Input to forcibly cancel EPS filter output hold
7	Laser start input
8	Calculation OFF input
9	Event log start input

FOR CHANNELS 1-4

Ch1 address (hex)	Ch2 address (hex)	Ch3 address (hex)	Ch4 address (hex)	Size	Access rights	Change en- abled mode	Description	Notes
3000	4000	5000	6000	1	R	-	1st edge posi- tion cell No.	
3001	4001	5001	6001	1	R	-	2nd edge posi- tion cell No.	
3002	4002	5002	6002	2	R	-	Actual 1st edge position	Integer, ± 999999 (in 0.1 µm increments)
3004	4004	5004	6004	2	R	-	Actual 2nd edge position	Integer, ± 999999 (in 0.1 µm increments)
3006	4006	5006	6006	2	R	-	1st edge position	Integer, ± 999999 (in 0.1 µm increments)
3008	4008	5008	6008	2	R	-	2nd edge position	Integer, ± 999999 (in 0.1 µm increments)
300A	400A	500A	600A	2	R	-	PV before hold	Integer, ± 999999 (in 0.1 µm increments)
300C	400C	500C	600C	2	R	-	PV after hold	Integer, ± 999999 (in 0.1 µm increments)
300E	400E	500E	600E	2	R	-	PV after moving average	Integer, ± 9999999 (in 0.1 µm increments)
3010	4010	5010	6010	2	R	-	Displayed value	Value displayed on controller without decimal point
3012	4012	5012	6012	2	R	-	Bottom value	Value displayed on controller without decimal point
3014	4014	5014	6014	2	R	-	Peak value	Value displayed on controller without decimal point
3016	4016	5016	6016	1	R	-	Analog output level	Percentage (0–100 %)
3017	4017	5017	6017	1	R	-	Event data	Table 3-A
3018	4018	5018	6018	1	R	-	1/8 of actual light intensity	Table 3-B
3019	4019	5019	6019	1	R	-	1/8 of normalized light intensity	Table 3-C
301A	401A	501A	601A	2	R	-		Integer
301C	401C	501C	601C	2	R	-	Estimated nor- malized light intensity	Integer
301E	401E	501E	601E	1	R	-	Normalized light in- tensity change rate	Percentage

Tuble 5 /	
Assignment	Event data
Bit 0	Pass event occurrence
Bit 1	Out event occurrence
Bit 2	High event occurrence
Bit 3	Low event occurrence
Bit 4	EPS event occurrence
Bit 5	Hold event occurrence
Bit 6	Smudge detection event occurrence
Bit 7	Output update event occurrence
Bit 8	Normal operation event occurrence
Bits 9–15	No assignment (always 0)

Table 3-A

Note: 1 = event occurrence, 0 = no occurrence

Table 3-B

Assignment	Actual light intensity distribution
Bit 0	Light intensity at the top margin is sufficient for receiver adjustment.
Bit 1	Light intensity at all cells in block 1 is sufficient for receiver adjustment (top).
Bit 2	Light intensity at all cells in block 2 is sufficient for receiver adjustment.
Bit 3	Light intensity at all cells in block 3 is sufficient for receiver adjustment.
Bit 4	Light intensity at all cells in block 4 is sufficient for receiver adjustment.
Bit 5	Light intensity at all cells in block 5 is sufficient for receiver adjustment.
Bit 6	Light intensity at all cells in block 6 is sufficient for receiver adjustment.
Bit 7	Light intensity at all cells in block 7 is sufficient for receiver adjustment.
Bit 8	Light intensity at all cells in block 8 is sufficient for receiver adjustment (bottom).
Bit 9	Light intensity at the bottom margin is sufficient for receiver adjustment.
Bits 10–15	No assignment (always 0)

Notes 1. A block is 1/8 of the measurement range. The number of cells differs for S07 and S15. 2. If receiver adjustment is possible, the value is 1. If not, the value is 0.

Table 3-C

Assignment	Normalized light intensity distribution
Bit 0	Not used (always 0)
Bit 1	Normalized light intensity in block 1 is 80 to 120 % (top).
Bit 2	Normalized light intensity in block 2 is 80 to 120 %.
Bit 3	Normalized light intensity in block 3 is 80 to 120 %.
Bit 4	Normalized light intensity in block 4 is 80 to 120 %.
Bit 5	Normalized light intensity in block 5 is 80 to 120 %.
Bit 6	Normalized light intensity in block 6 is 80 to 120 %.
Bit 7	Normalized light intensity in block 7 is 80 to 120 %.
Bit 8	Normalized light intensity in block 8 is 80 to 120 % (bottom).
Bits 9–15	No assignment (always 0)

Notes 1. A block is 1/8 of the measurement range. The number of cells differs for S07 and S15. 2. If receiver adjustment is possible, the value is 1. If not, the value is 0.

FOR LIGHT INTENSITY

Address (hex)	Size	Access rights	Change en- abled mode	Description	Notes
7000	1	W	RDY, RUN	Type of light intensity data to acquire	Table 4-A
7100	1	R	-	Data for cell 1 Top	Type of light intensity data specified by 7000
7101	1	R	-	Data for cell 2	Type of light intensity data specified by 7000
7102	1	R	-	Data for cell 3	Type of light intensity data specified by 7000
7103	1	R	-	Data for cell 4	Type of light intensity data specified by 7000
7104	1	R	-	Data for cell 5	Type of light intensity data specified by 7000
7105	1	R	-	Data for cell 6	Type of light intensity data specified by 7000
7106	1	R	-	Data for cell 7	Type of light intensity data specified by 7000
:	:	:	÷	:	:
71FF	1	R	-	Data for cell 256 Bottom	Type of light intensity data specified by 7000

Note: When the K1G-S07 is connected, 7180–71FF are 0.

Table 4-A

Value	Type of light intensity data to acquire
0	Return a response without acquiring data.
1	Channel 1: normalized light intensity
2	Channel 2: normalized light intensity
3	Channel 3: normalized light intensity
4	Channel 4: normalized light intensity
5	Channel 1: actual light intensity when the laser diode (LD) = ON
6	Channel 2: actual light intensity when the LD = ON
7	Channel 3: actual light intensity when the LD = ON
8	Channel 4: actual light intensity when the LD = ON
9	Channel 1: actual light intensity when the LD = OFF
10	Channel 2: actual light intensity when the LD = OFF
11	Channel 3: actual light intensity when the LD = OFF
12	Channel 4: actual light intensity when the LD = OFF
13	Channel 1: normalized parameter
14	Channel 2: normalized parameter
15	Channel 3: normalized parameter
16	Channel 4: normalized parameter
17 and later	Message is ignored.

FOR ADJUSTMENT

Address (hex)	Size	Access rights	Change en- abled mode	Description	Notes
8000	1	W	RDY, RUN	Receiver adjustment	Table 5-A
8001	1	R	-	Channel 1: adjustment result	0: Adjustment in progress 1: Succeeded 2: Failed
8002	1	R	-	Channel 2: Adjustment result	0: Adjustment in progress 1: Succeeded 2: Failed
8003	1	R	-	Channel 3: Adjustment result	0: Adjustment in progress 1: Succeeded 2: Failed
8004	1	R	-	Channel 4: Adjustment result	0: Adjustment in progress 1: Succeeded 2: Failed
8100	1	W	RDY, RUN	Zero adjustment	Table 5-A
8101	1	R	-	Channel 1 zero adjust- ment result	0: Adjustment in progress 1: Complete
8102	1	R	-	Channel 2 zero adjust- ment result	0: Adjustment in progress 1: Complete
8103	1	R	-	Channel 3 zero adjust- ment result	0: Adjustment in progress 1: Complete
8104	1	R	-	Channel 4 zero adjust- ment result	0: Adjustment in progress 1: Complete
8200	1	W	RDY, RUN	Analog output low limit adjustment	Table 5-A
8201	1	R	-	Channel 1 analog output low limit adjustment result	0: Adjustment in progress 1: Complete
8202	1	R	-	Channel 2 analog output low limit adjustment result	0: Adjustment in progress 1: Complete
8203	1	R	-	Channel 3 analog output low limit adjustment result	0: Adjustment in progress 1: Complete
8204	1	R	-	Channel 4 analog output low limit adjustment result	0: Adjustment in progress 1: Complete
0200	1	14/		Angle a subsut black P. 19	
8300	1	W	RDY, RUN	Analog output high limit adjustment	Table 5-A
8301	1	R	-	Channel 1 analog output high limit adjustment result	
8302	1	R	-	Channel 2 analog output high limit adjustment result	
8303	1	R	-	Channel 3 analog output high limit adjustment result	0: Adjustment in progress 1: Complete

Adduses		A	Changes		
Address (hex)	Size	Access rights	Change en- abled mode	Description	Notes
8304	1	R	-	Channel 4 analog output high limit adjustment result	0: Adjustment in progress 1: Complete
8400	1	W	See table men- tioned at right	Controller mode change	Table 5-B2
8401	1	R	-	Controller mode	Current mode Table 5-B1
8402	1	W	RUN	Return to Run mode	1: Execute
8500	1	W	RDY	Save data to EEPROM	1: Execute
8501	1	R	-	Progress of data copy to EEPROM	0: In progress 1: Complete
8600	1	W	RUN	Forcibly cancel EPS filter output hold	1: Execute
8700	1	W	RDY, RUN	Event log start	1: Execute
8800	1	W	RDY, RUN, UT	Channel change	Table 5-C
8801	1	R	-	Channel selection status	
8900	1	W	RUN	Peak/bottom value switch	0: Peak 1: Bottom
8901	1	W	RUN	Peak/bottom value deletion	1: Execute
8A00	1	W	RUN	Disabling of key lock	"1" disables
8A01	1	R	-	Key lock status	0: Key lock off 1: Key lock on
8B00	1	W	RUN	RUN Disabling of controller power-saving	
8B01	1	R	-	Sleep status	0: Sleep off 1: Sleep on
8C00	1	W	RDY, RUN	(Reserved)	Do not write data.
8C01	1	R	-	(Reserved)	0 can be read.
8D00	1	W	RDY, RUN	Laser emission stop	1: Laser stop 0: Laser start
8D01	1	R	-	Laser status	0: Laser ON 1: Laser OFF
8E00	1	W	All	Disabling of all keys	1: Disables all keys 0: Enables all keys
8E01	1	R	-	Status of key dis- abling	1: All keys are enabled 0: All keys are disabled
8E02	1	W	RDY	Sensor head recognition	Table 5-D
8F00	1	W	UT	AO1 test output	Value to be written to AO (0–100 %)

9-6 Communication Parameters

Address (hex)	Size	Access rights	Change en- abled mode	Description	Notes
8F01	1	W	UT	AO2 test output	Value to be written to AO (0–100 %)
8F02	1	W	UT	AO3 test output	Value to be written to AO (0–100 %)
8F03	1	W	UT	AO4 test output	Value to be written to AO (0–100 %)
8F04	1	W	UT	DO test output	Bits 0–7 are assigned to DO1–DO8.

Table 5-A

Value	Operation			
0	Take no action but return a response.			
1	Channel 1: execute			
2	Channel 2: execute			
3	Channel 3: execute			
4	Channel 4: execute			
5	All channels: execute			
6 and later	An error message is returned.			

Table 5-B1 When data is read

	-
Value	Mode
0	FirstBoot mode
1	Ready mode
2	Run mode
3	Test mode
4	Failure mode
5	Adjust mode
6	Config mode

Table 5-B2 Mode correspondence table for changing the mode using communication when data is written

Current made	Т	Target mode				
Current mode	Ready	Run	Test			
Ready	-	~	v			
Run	~	-	v			
UserTest	v	~	-			

If the mode is changed to a mode indicated as -, an application error will occur.

Tal	ble	5-0	C

	Value	Channel selection			
0		Take no action but return a re-			
		sponse.			
	1	Channel 1: select			
	2	Channel 2: select			
	3	Channel 3: select			
	4	Channel 4: select			
	5 and later	An error message is returned.			

Table 5-D	
Value	Sensor head recognition
0	Take no action but return a re-
	sponse.
1	Channel 1: recognize
2	Channel 2: recognize
3	Channel 3: recognize
4	Channel 4: recognize
5 and later	An error message is returned.

FOR SPECIAL FUNCTIONS

• Shared settings

Address (hex)	Size	Access rights	Change en- abled mode	Description	Notes
F000	1	R/W			0: Voltage output 1: Current output *
F001	1	R/W	RDY	Output type (2): NPN/ PNP	0: NPN 1: PNP *
F002	1	R/W	RDY, RUN	Event source	0: Any 1: CH1 2: CH2 3: CH3 4: CH4
F003	1	R/W	RDY, RUN	Event type	Table 6-A
F004	1	R/W	RDY, RUN	Designation of chan- nel for sensor head snapshot	1: CH1 2: CH2 3: CH3 4: CH4
F005	1	R/W	RDY, RUN	Trigger point setting	Table 6-B
F006	1	R/W	RDY, RUN	High-speed trend channel	1: CH1 2: CH2 3: CH3 4: CH4
F007	1	R/W	RDY, RUN	Re-sampling counter	1 to 4000

* When a parameter is written, add AA00 in hexadecimal (43520 in decimal) to it.

Event log data for individual PVs

PV1 address (hex)	PV2 address (hex)	PV3 address (hex)	PV4 address (hex)	Size	Access rights	Change enabled mode	Description
F100	F200	F300	F400	2	R	-	Event log PV time 01
F102	F202	F302	F402	2	R	-	Event log PV time 02
F104	F204	F304	F404	2	R	-	Event log PV time 03
F106	F206	F306	F406	2	R	-	Event log PV time 04
F108	F208	F308	F408	2	R	-	Event log PV time 05
F10A	F20A	F30A	F40A	2	R	-	Event log PV time 06
F10C	F20C	F30C	F40C	2	R	-	Event log PV time 07
F10E	F20E	F30E	F40E	2	R	-	Event log PV time 08
F110	F210	F310	F410	2	R	-	Event log PV time 09
F112	F212	F312	F412	2	R	-	Event log PV time 10
F114	F214	F314	F414	2	R	-	Event log PV time 11
F116	F216	F316	F416	2	R	-	Event log PV time 12
F118	F218	F318	F418	2	R	-	Event log PV time 13
F11A	F21A	F31A	F41A	2	R	-	Event log PV time 14
F11C	F21C	F31C	F41C	2	R	-	Event log PV time 15
F11E	F21E	F31E	F41E	2	R	-	Event log PV time 16
F120	F220	F320	F420	2	R	-	Event log PV time 17
F122	F222	F322	F422	2	R	-	Event log PV time 18
F124	F224	F324	F424	2	R	-	Event log PV time 19
F126	F226	F326	F426	2	R	-	Event log PV time 20
F128	F228	F328	F428	2	R	-	Event log PV time 21
F12A	F22A	F32A	F42A	2	R	-	Event log PV time 22
F12C	F22C	F32C	F42C	2	R	-	Event log PV time 23
F12E	F22E	F32E	F42E	2	R	-	Event log PV time 24
F130	F230	F330	F430	2	R	-	Event log PV time 25
F132	F232	F332	F432	2	R	-	Event log PV time 26
F134	F234	F334	F434	2	R	-	Event log PV time 27
F136	F236	F336	F436	2	R	-	Event log PV time 28
F138	F238	F338	F438	2	R	-	Event log PV time 29
F13A	F23A	F33A	F43A	2	R	-	Event log PV time 30
F13C	F23C	F33C	F43C	2	R	-	Event log PV time 31
F13E	F23E	F33E	F43E	2	R	-	Event log PV time 32

• Event log snapshot data

Address (hex)	Size	Access rights	Change enabled mode	Description
F500	1	R	-	Event log snapshot cell 1
F501	1	R	-	Event log snapshot cell 2
:	:	÷	:	:
F5FE	1	R	-	Event log snapshot cell 255
F5FF	1	R	_	Event log snapshot cell 256

Table 6-A

Value	Event log trigger setting				
0	Pass event occurrence				
1	Out event occurrence				
2	High event occurrence				
3	Low event occurrence				
4	ESP event occurrence				
5	Hold state occurrence				
6	Smudge detection (abnormal light intensity)				
7	Event log start input ON				

Table 6-B

Value	Event log trigger point setting		
0	25 % (8 points before, 24 points after trigger)		
1	50 % (16 points before and after trigger)		
2	75 % (24 points before, 8 points after trigger)		

9-7 Important Notes for Restarting the Laser Beam

This device can control the state of laser beam emission using laser start input, RS-485 communication, and setting tool communication functions. These functions can be used to restart laser emission as follows.

Example: Using laser start input

Initial status is RUN mode and laser start input is ON.

- **1.** Stop control operation that uses analog output.
- **2.** Turn off laser start input to turn the laser beam off (analog output becomes invalid).
- **3.** Change to READY mode to prepare for laser beam start.
- 4. Turn on laser start input to start measurement.
- 5. Change to RUN mode (analog output becomes valid).
- **6.** Wait for the circuits to stabilize (approximately 30 minutes, the same as the warm-up time).
- 7. Start control operation that uses analog output.



"Invalid" analog output is the state in which analog output is not updated, and "valid" is the state in which analog output is updated according to the results of measurement.

If the circuit stabilization time (above, **6**) is not sufficient, measurements that do not satisfy the accuracy specification may be reflected in the analog output. For controllers manufactured in and after September 2017, by following **step 4** above and turning on laser start input, analog output becomes valid. (**Steps 3** and **5** can be omitted.) However, make sure that the circuit stabilization time is sufficient.



Revision History of CP-SP-1397E

Printed	Edn.	Revised pages	Description
Sep. 2016	1		
June 2017	2	ii iv viii ix x 1-2 1-4 to 1-5 1-12 1-13 2-15 3-2 3-11 4-4 4-5 to 4-7 4-8 to 4-90 5-1 7-5 7-7 8-5 8-6 9-2 9-8	A caution was added to "CAUTIONS AND WARNINGS." Descriptions in "THE ROLE OF THIS MANUAL" were changed. "COMMUNICATION CABLES FOR EtherCAT" was added. Descriptions in "WIRING OF THE POWER AND GROUND" were changed. A description was added to "POWER-ON RESET." "If K1G-C04MG is used" was changed to "If K1G-C04MG or K1G-C04EG is used." Descriptions were changed. A drawing of the back of K1G-C04EG was added. Descriptions of RJ45 ports and EtherCAT RUN/ERROR LEDs were added to the table. Section 2-7, "Wiring the Controller (K1G-C04EG)," was added. Descriptions and the flowchart in "Initial Setup Flowchart" were changed. Section 3-7, "Setting the ECAT ID (for K1G-C04EG)," was added. Descriptions were changed. Page numbers were formerly 4-6 and following Descriptions in "CHANGING SMUDGE DETECTION FUNCTION SETTINGS" were changed. A description was added. K1G-C04EG was added to the table. Drawings of K1G-C04EG (controller) were added. EtherCAT communication problems were added to "TROUBLE SHOOTING." ERROR 512 was added. The note for A10 was changed. A flowchart for K1G-C04E initial setting was added.
July 2018	3	9-9 4-36	"EtherCAT communication status check display" was added. A reference was added for laser start input in the table.
		9-31	Section 9-7, "Important Notes for Restarting the Laser Beam," was added.



Azbil Corporation Advanced Automation Company

1-12-2 Kawana, Fujisawa Kanagawa 251-8522 Japan

URL: http://www.azbil.com

Specifications are subject to change without notice. (09)